

OLYMPUS®

IS-3DLX

■ INSTRUCTIONS

- Before using your IS-3DLX, read this manual carefully to ensure correct use.
- We recommend that you take test shots to get accustomed to your IS-3DLX before taking important photographs.

CAMERA
MAINTENANCE

TAKING BETTER
PICTURES


ADDITIONAL
FUNCTIONS

Thank you for purchasing the Olympus IS-3DLX.

MAIN FEATURES

- Built-in 35mm ~ 180mm approx. 5X zoom lens for increased shooting range.
- Powerful built-in, dual-element intelligent flash system rated at GN 28 (ISO100·m)/GN 92 (ISO100·ft), for telephoto and GN 20 (ISO100·m)/GN 66 (ISO100·ft), for wide angle, corresponding to distant subjects and zoom shooting with high magnification and assuring beautiful pictures.
- ED (extraordinary dispersion) glass is used in the lens, achieving crisp, clear images with high contrast.
- The standard shooting mode lets anyone take beautiful pictures easily.
- Panorama photographs are possible when the optional panorama adapter is attached.
- Other various easy-to-use functions include versatile flash, subject, drive, and exposure modes and more.
- Optional remote control for Bulb shooting, etc.
- Date imprinting function.

Symbols used in this manual:



PREPARATIONS	Names and functions of parts	4	Loading the batteries	10
	Viewfinder display/LCD panel	6	Checking the batteries.....	11
	Attaching the strap	7	Points to remember	12
	Outline of operations	8	Reset operation	14


BASIC OPERATIONS	Loading the film	15
	Taking pictures	18
	Unloading the film	21


ADDITIONAL FUNCTIONS	Using the focus lock	22	Using the drive modes	47
	Flash photography	23	Power focus	52
	Selftimer	30	Spot metering	53
	Macro photography	32	Zoom exposure	54
	Using the exposure modes	34	Autofocus beep	55
	Flash photography in the manual exposure mode	45	Remote control (optional)	56
	Exposure compensation.....	46	Printing the date and time	61
			Correcting the data	62

TAKING BETTER PICTURES	Flash	63	Exposure compensation.....	75
	Electronic flash G40 (optional)	65	Film speed.....	75
	Effects of zoom and its advantages ..	68	Macro photography.....	76
	Autofocus (AF)	70	Panorama photography.....	77
	Exposure	72	Accessories (optional).....	78
	Metering the amount of light	74		

CAMERA MAINTENANCE	Care and storage	79
	Battery handling	80
	Troubleshooting	81
	Questions and answers	84
	Specifications	85


NAMES AND FUNCTIONS OF PARTS






VIEWFINDER DISPLAY/LCD PANEL


VIEWFINDER DISPLAY




LCD PANEL




ATTACHING THE STRAP



1




2




3

OUTLINE OF OPERATIONS


Basic Shooting Procedures




Load the batteries (p. 10).



Open the back cover (p. 15).



Load the film (p. 15).




Press the zoom buttons to determine the composition (p. 18).




Place the autofocus frame on the subject you want to focus on (p. 19).




Depress the shutter release button halfway, making sure the autofocus indicator in the viewfinder lights and the autofocus beep is heard (p. 20).




Close the back cover (p. 17).




Turn the power switch ON (p. 17).




Make sure the exposure counter on the LCD panel reads " 1 " (p.17).



Depress the shutter release button fully to take a picture (p. 20).



When the film reaches the end, it will automatically rewind (p. 21).




Open the back cover to remove the rewind film (p. 21).


LOADING THE BATTERIES

Use two 3V lithium batteries (CR123A or DL123A).

1. Turn the lock screw on the bottom of the camera counterclockwise to open the battery cover.



2. Insert the batteries as shown and replace the cover, turning the lock screw clockwise.




- The types of batteries that can be used are also shown inside the battery cover.
- When replacing the batteries, make sure to turn the power switch OFF before unloading the batteries.


● Read "Battery Handling" on page 80.

CHECKING THE BATTERIES

1. Turn the power switch ON.



2. Press the exposure mode and +/- buttons simultaneously to check the batteries.



Batteries are OK.
The mark disappears
when the finger is
released from the
button.



Blinks

Batteries are
low.
Have spares
handy.




Lights

Batteries
should be
replaced
immediately.

POINTS TO REMEMBER

Hold the Camera Correctly.



Correct.



Correct.




Incorrect.

Note: As the focal length becomes larger, shaking the camera becomes more noticeable. Hold the camera firmly with both hands while keeping elbows at sides to prevent the camera from shaking.

Caution:
Keep your fingers away from the lens, AF illuminator and flash.

Proper Shutter Release. Practice before loading the film.

1. Keep the shutter release button depressed halfway.




To lock the focus.

Make sure

The image is clear, the autofocus beep is heard, and the autofocus indicator lights in the viewfinder.

2. Depress the shutter release button fully.



To release the shutter and take the picture.

Note: When the autofocus indicator doesn't light, the shutter won't release. (See p. 70.)

Cautions:


- Press the shutter release button gently.

Avoid shaking the camera when pressing the shutter release button to prevent blurry pictures.

RESET OPERATION

Reset operation restores the standard shooting mode, for worry-free photography that anyone can perform. Also use this mode when you don't know what operation to perform.

Press the exposure mode and +/- buttons simultaneously.



The camera will return to the standard shooting mode, and other set modes will be canceled.


Standard Shooting Mode

Exposure mode: Program Auto (P)
Drive mode: Single (S)*
Light metering mode: ESP
Flash mode: AUTO or AUTO-S
Exposure compensation: ± 0
Focusing: AF
Autofocus beep: On

* This mode won't be restored by performing the reset operation once the Double Exposure mode is activated and the first shot is taken. (See p. 50.)


LOADING THE FILM

1. Slide the back cover release upward to open the back cover.



Shutter curtains



2. Push in the film cartridge until it clicks.



Note: Use DX-coded film.
Caution: Do not touch the shutter curtain, and do not press it with the edge of film.


3. Pass the edge of the film under the film guide, and align the film leader with the film loading indicator.

Film loading indicator Film guide




Note: Make sure the film is lying flat. If not, push the cartridge down.

4. Close the back cover.



The film automatically advances to the first frame.

5. Turn the power switch ON.



Make sure


The exposure counter on the LCD panel reads 1.

Note: If **E** blinks in the exposure counter, reload the film.

TAKING PICTURES

Follow the procedure here to cover ordinary photography.


1. Remove the lens cap, and turn the power switch ON.



Make sure The lens advances, and the LCD panel lights.

Note: If no operation is made for approx. 30 seconds, the LCD panel goes out and will come on again when the operation is resumed.

2. While looking through the viewfinder, press the zoom button to determine the composition.




There are two zoom speeds. Press the zoom button halfway for slow zooming and fully for fast zooming.

How to Use the Zoom Buttons

Telephoto: Press the **T** button to zoom in.




Max. telephoto focal length: 180mm




Wide-angle: Press the **W** button to zoom out.



Max. wide-angle focal length: 35 mm



3. Position the autofocus frame on your subject.



Autofocus frame

Working distance 1.2 m (3.9 ft) ~ ∞

4. Depress the shutter release button halfway.



(Make sure) The autofocus beep is heard and the autofocus indicator lights when the subject is in focus. It will blink if the subject is difficult for the autofocus to lock on, and when the subject is too close.

Note: When the autofocus indicator blinks, the shutter won't release. (See p. 70.)

5. Depress the shutter release button fully to take the picture.




The shutter releases and the film automatically advances to the next frame.

UNLOADING THE FILM


The camera automatically rewinds the film when you reach the end of a roll.

Make sure the motor has stopped and the **E** is blinking on the LCD panel, before opening the back cover and removing the film.

Rewinding the film before the end of the roll



- If the power is turned OFF while rewinding, operations will stop. Rewind mode, however, is not canceled. Rewinding will continue when the power switch is turned ON again.
- The final number of exposures may sometimes exceed the number of exposures specified on the film.



After confirming that the power is ON, press the mid-roll rewind button with the tip of a ballpoint pen, or the like. Do not use an instrument with a sharp tip.

USING THE FOCUS LOCK

When the main subject is not in the center of the Autofocus frame, use the focus lock.

1. Position the autofocus frame on your subject and press the shutter release button halfway.
2. Reposition your subjects in the picture frame while keeping the shutter release button depressed halfway. Then press the shutter release button fully.



Make sure

The autofocus beep is heard, and the autofocus indicator lights in the viewfinder.

Autofocus frame



Note:

- When the focus is locked, the exposure is also locked (AE lock).

FLASH PHOTOGRAPHY

This camera has two flash tubes that are automatically selected and fired according to the shooting conditions. There are also various flash modes that can be selected to match your needs.


Flash Modes

Mode	Function
AUTO	Automatically fires in low-light conditions. (p. 26)
AUTO-S	Significantly reduces the phenomenon of "red-eye" (when a subject's eyes appear red). (p. 28)
FILL-IN	Fires regardless of available light. (p. 29)


Note: See p. 45 for flash photography in the Manual Exposure mode.

How to Select the Flash Mode

1. Slide the flash release to flip up the flash.




2. Press the flash button.




The available modes appear, and ► blinks on the left of the mode currently engaged.


3. While pressing the flash button, select the mode using the shift buttons or shift dial,



4. Release the flash button to engage the mode.



Make sure ► is blinking on the left of the selected flash mode.



Make sure ► disappears, and the engaged flash mode remains on the LCD panel.


Auto Flash AUTO

The flash fires automatically when there is insufficient light.

1. When ⚡ blinks in the viewfinder, the flash should be used. Slide the flash release.



2. When the flash is flipped up, the camera will start recharging the flash.



Make sure **AUTO** lights on the LCD panel. When the flash is recharged, ⚡ in the viewfinder will light.

Note: The flash won't fire until recharging is finished.

3. Press the shutter release button.



Auto Flash Range*

(with color negative film)

Focal length	35mm	180mm
ISO 100	6.3 m (20.7 ft)	7 m (23 ft)
ISO 200	8.9 m (29.2 ft)	9.8m (32.2ft)
ISO 400	12.6m (41.3 ft)	14 m (45.9 ft)


* The Auto Flash mode can be combined with the Macro mode.

Note: The shutter speed is automatically set at 1/100-sec. when the flash fires. If the subject requires a faster shutter speed, the flash won't fire.

Red-Eye Reducing Flash AUTO-S

Approximately 20 pre-flashes are emitted before the main flash fires, significantly reducing the phenomenon of "red-eye" (when a subject's eyes appear red). This mode is the same as Auto Flash except for the pre-flashes.

1. Flip up the flash, and select the Auto-S mode.
2. Press the shutter release button.




Notes:

- The pre-flashes are not emitted in the Sports mode.
- After pressing the shutter release button, hold the camera securely until the shutter has been released.
- To cancel the Auto-S mode, select another mode following the procedure on page 23.

Forced Activation FILL-IN


In this mode, the flash always fires. Even in backlighting, both the subject and background can be shot clearly. And portraits look lively by reflecting light into the subject's eyes.

1. Make sure the exposure mode is set to **P** (program).



In exposure modes other than Program, the FILL-IN Flash mode cannot be engaged.


2. Flip up the flash, and select the FILL-IN Flash mode. Press the shutter release button.



Note: The shutter speed is automatically set at 1/100-sec.


SELFTIMER

1. Press the selftimer/
remote control button.
 is displayed on the
LCD panel.



Note: When the selftimer/remote control button is pressed again,  will start blinking, but the selftimer will operate in the same manner as when  lights.

2. Position the autofocus frame
on the subject. Press the
shutter release button half-
way to focus on the subject.



The focus and exposure will
be locked.

Important: Do not press the shutter release button while standing in front of the camera as this may cause out-of-focus pictures.

3. Press the shutter release button fully to activate the selftimer.



The shutter will be released
12 seconds later.

Make sure The viewfinder display disappears and the AF illuminator blinks during the operation.

Notes:

- Use a tripod, etc., to hold the camera steady.
- The selftimer will be automatically canceled after the shot.
- To cancel the selftimer in the middle of operation, press the selftimer button again.


Important:

To prevent backlight from entering through the viewfinder, do not move your eye from the viewfinder when you press the shutter release button.


MACRO PHOTOGRAPHY

Close-up photography is possible at working distance of 0.6 m (2 ft) to ∞ , between focal lengths of 35 mm and 120 mm.

1. Press the macro button.




Note: When the lens is at a setting greater than 120 mm, it will be withdrawn to 120 mm automatically.



Make sure  appears both in the viewfinder and on the LCD panel.

2. Press the zoom buttons
to determine the
composition.




Note: To cancel the Macro mode, press the macro button again.

USING THE EXPOSURE MODES


There are seven exposure modes: four with preset settings for easy shooting in various common situations, and three allowing you to select your own settings.

Exposure Modes

Program Auto (ESP metering)
Standard exposure mode for ordinary shooting.



The modes are accessed in the order shown



For creative expressions making good use of your experience:

A Aperture-Preferred Auto (center-weighted average metering) (P. 41)

The aperture is set manually, and the camera automatically controls the correct shutter speed.

S Shutter-Preferred Auto (center-weighted average metering) (P. 42)

The shutter speed is set manually, and the camera automatically controls the correct aperture.

M Manual Exposure (center-weighted average metering) (P. 43)

Both the aperture and shutter speed are set manually.

For easy, effective shooting in various common situations:

 Sports (P. 36)
For fast-moving subjects.


 Portrait (P. 37)
For pictures with blurred backgrounds for "portrait" effect.

 Landscape (P. 38)
For pictures with extended in-focus backgrounds.

 Night Scene (P. 39)
For night scenes or night scenes with subjects in the foreground.

How to Select the Exposure Mode


1. While pressing the mode button, select the mode using the shift buttons or shift dial.



Make sure

► blinks to show the selected exposure mode.

2. Release the mode button to engage the mode.



Make sure

The engaged exposure mode lights.


SPORTS

To shoot fast-moving subjects.

In this mode, the camera automatically selects both a faster shutter speed and the Continuous Shooting mode. This results in increased clarity, and lets you capture fast moving photo opportunities you might otherwise miss.

1. Select the Sports mode to display  on the LCD panel.

2. As long as the shutter release button is pressed, the shutter will release continuously.



Notes:


- In the Sports mode, for faster flash response, Auto-S pre-flashes will not be emitted.
- The camera exposes a maximum of two frames per second.

PORTRAIT

To take pictures with blurred backgrounds for a "portrait" effect.

Portrait mode lets you take beautiful portrait photographs. This is especially effective when the lens is at the telephoto setting.

1. Select the Portrait mode to display  on the LCD panel.



Note: The aperture is wide open.

2. Press the shutter release button.




LANDSCAPE

To take pictures with extended in-focus backgrounds.

When shooting landscapes or landscapes with subjects in the foreground, both the nearest and farthest objects are sharply in focus.

1. Select the Landscape mode to display  on the LCD panel.



2. Press the shutter release button.



Note: Set the lens at wide angle for optimal results.


NIGHT SCENE

To shoot night scenes or night scenes with subjects in the foreground.

In this mode, the camera automatically selects the ideal exposure compensation for shooting night scenes free of subjects, and for shooting night scenes with subjects in the foreground.

Shooting Night Scenes Free of Subjects

1. Select the Night Scene mode to display  on the LCD panel.
2. Press the shutter release button.



Shooting Night Scenes with Subjects in the Foreground (Slow-Synchro)

Engage the Night Scene mode. Flip up the flash. Press the shutter release button.



Both the subject and background will be perfectly exposed.

Note: Since a slow shutter speed is automatically selected in low-light situations, the use of a tripod is recommended to prevent blurred pictures caused by shaking the camera.

Shutter speeds in the Night Scene mode: Wide-angle: 3 sec. max. Telephoto: 4 sec. max. (With negative color film, ISO 100)

With Auto Flash




In the Auto Flash mode, only the subject in the foreground can be shot.


APERTURE-PREFERRED AUTO A

The background blur can be controlled by adjusting the aperture setting. The shutter speed will be selected automatically.

Enter the Aperture-Preferred Auto mode. Press the shift buttons to adjust the aperture setting.




Note: If the shutter speed indicator blinks, adjust the aperture until the shutter speed lights steadily.



Larger aperture

F5.6



Smaller aperture

F22




Larger aperture settings will often give a blurred background, and smaller aperture settings will give a sharper background


SHUTTER-PREFERRED AUTO S

Subjects in motion can be captured by adjusting the shutter speed. The aperture will be controlled automatically.

Enter the Shutter-Preferred **S** Auto mode. Turn the shift dial to adjust the shutter speed.




Note: If the aperture indicator blinks, adjust the shutter speed until the aperture indicator lights steadily.



Slower shutter speed

1/60-sec.



Faster shutter speed

1/500-sec.




When the shutter speed is set slower, fast-moving subjects will be blurred, showing motion. When it's set faster, fast-moving subjects will be frozen in stop-motion.


MANUAL EXPOSURE ^M

Both the shutter speed and aperture can be set as desired to reflect your photographic intentions.

1. Select the Manual Exposure mode to display **M** on the LCD panel.




2. Press the shift button to adjust the aperture.




Note: Exposure compensation cannot be performed in the Manual Exposure mode.

3. Turn the shift dial to adjust the shutter speed.




4. The exposure level will be displayed on the LCD panel and in the viewfinder.



- + Blinks: Overexposed
- + Lights: Slightly overexposed
- ± Lights: Correctly exposed
- Lights: Slightly underexposed
- Blinks: Underexposed

FLASH PHOTOGRAPHY IN THE MANUAL EXPOSURE MODE

1. Flip up the flash, and set the shutter speed to 1/100-sec, or slower.



2. Set the aperture setting according to the camera-to-subject distance in the table below,

Aperture setting (color negative film)


	Zoom Macro			Standard				
Distance	0.6 ~ 0.8m	0.8 ~ 1m	1 ~ 1.2m	1.2 ~ 1.5m	1.5 ~ 2m	2 ~ 2.5m	2.5 ~ 3.2m	3.2 ~ 4m
	2.0 ~ 2.6ft	2.6 ~ 3.3ft	3.3 ~ 3.9ft	3.9 ~ 4.9ft	4.9 ~ 6.6ft	6.6 ~ 8.2ft	8.2 ~ 10.5ft	10.5 ~ 13.1ft
ISO 50	F22	F16	F13	F11	F8	F6.7	F5.6	—
ISO 100		F22	F19	F16	F11	F9.5	F6.7	F5.6
ISO 200	—	—	—	F22	F16	F13	F9.5	F8
ISO 400	—	—	—	—	F22	F19	F13	F11

Calculation formula for ISO 100: Aperture setting = $\text{GN}20 \div \text{Distance (m)}$
 Aperture setting = $(\text{GN}66 \div \text{Distance (ft)})$

EXPOSURE COMPENSATION

The exposure compensation levels can be set up to $\pm 4\text{EV}$ in $1/3\text{EV}$ steps.

1. While pressing the +/- button, set the desired compensation level using the shift buttons or shift dial.



Make sure The exposure level is displayed in the viewfinder and on the LCD panel.

Note: While pressing the +/- button, the exposure counter changes to the compensation level display.

+2EV



$\pm 0\text{EV}$



-2EV



USING THE DRIVE MODES DRIVE


There are two film-advance modes in addition to the standard single-frame advance mode.

Drive Modes

Display	Function
SINGLE	Single Standard single-frame advance mode
CONT.	Continuous Shooting The camera releases the shutter continuously while keeping moving subjects in focus and correctly exposed. (p. 49)
D.EXP.	Double Exposure You can combine two images on a single frame. (p. 50)


Selecting the Drive Mode

1. Press the drive button.



The available modes appear, and ► blinks on the left of the mode currently engaged.


2. While pressing the drive button, select the mode using the shift buttons or shift dial.



Make sure

► is blinking on the left of the selected drive mode.

3. Release the drive button to engage the mode.




Make sure

► disappears, and the engaged drive mode remains on the LCD panel.


CONTINUOUS SHOOTING CONT.

The camera releases the shutter continuously while keeping moving subjects in focus and correctly exposed.

1. Select the Continuous Shooting mode to display **CONT.** on the LCD panel.



2. While the shutter release button is fully pressed, the shutter releases continuously.




Notes:

- The camera exposes a maximum of approximately 2 frames per second.
- When used in combination with the flash, the flash may not fire after the second frame. The exposure will be adjusted automatically instead.
- The autofocus beep will not function even when the subject is in focus.

DOUBLE EXPOSURE D.EXP.

You can expose two images on a single frame.

1. Select the Double Exposure mode to display **D.EXP.** on the LCD panel.



2. Press the shutter release button fully to take the first exposure.



Make sure

D.EXP. on the LCD panel will blink.
The film will not be advanced.

3. Take the second exposure.
The film will advance, and
the Double Exposure
mode will be canceled.




Note: The Double Exposure mode
cannot be canceled after the first shot
(See p. 14).


Power Focus

When the distance at which you want to shoot is predetermined, you can set the focus in advance and wait until the photo opportunity comes. Manual focusing is possible in this mode, so PF can also be used when autofocusing is difficult (see P. 70).

1. When you want to wait until the photo opportunity comes, focus on the subject first by using autofocus. Then press the PF button.
2. After making sure  is blinking on the LCD panel, press the shutter release button when the photo opportunity comes.



Note: Manual focusing is possible using the zoom buttons, but zooming cannot be performed in the PF mode. To cancel the PF mode, press the PF button again.





Note: There are two PF speeds, available for manual focusing, functioning in the same manner as the zoom.

SPOT METERING


In this mode, the camera limits light metering to a particular area, such as a subject's face, and sets the correct exposure.

1. Position the subject for spot metering within the spot frame, and press the SPOT button.



Make sure  will be displayed on the LCD panel and in the viewfinder, and the exposure is locked.

2. Recompose the shot, then press the shutter release button to take the picture.




Notes:

- When the flash is flipped up, or the Night Scene mode is engaged, the camera does not perform spot metering.
- After the shot, the Spot Metering mode is canceled. To cancel the mode without taking a shot, press the SPOT button again.

ZOOM EXPOSURE

Using this mode, the film is exposed while zooming, resulting in intriguing "streaked" images.


1. Select the Night Scene mode to display  on the LCD panel, Set the focal length where you want to start zooming.



Notes:

- This exposure method is most effective when the focal length is set at either the maximum (180 mm) or the minimum (35 mm) setting.
- Use the flash when photographing a person.

2. While pressing the shutter release button halfway to keep the subject in focus, press either W or T on the zoom buttons.



Note: The lens will not move until the shutter release button is fully pressed.

AUTOFOCUS BEEP


3. While keeping the zoom button depressed, press the shutter release button fully to take the picture.



Note: If the shutter speed is faster than 1/3-sec., zoom exposure will automatically be canceled, and the camera will operate in the standard Night Scene mode.

When not required, the beep can be overridden.

Press the drive and flash buttons simultaneously to override the beep. To reactivate it, press the buttons again.




When overriding or reactivating the beep, a confirmation beep is heard.
Note: When the power is switched off and on again, the beep will be functioning.

REMOTE CONTROL (OPTIONAL)

The optional RC-100 Remote Control is required.

1. Press the selftimer/remote  control button to engage the Remote Control mode.



Press	Display	Shutter will be:
Once	 Lights	Released 3 sec. later
Twice	 Blinks	Released right away
Thrice	Goes out	Canceled


2. Position the autofocus frame on the subject.



Note: When there is no subject in the position you want to focus on, first focus on an object at the same distance as the desired position. Then enter the PF mode, and recompose the frame. (See page 52.)

3. Aim the remote control at the camera from within the range shown in the illustrations below, and press the button. The shutter will be released after the autofocus beep is heard and the AF illuminator blinks.


When releasing the shutter from in front of the camera:



Notes:

- Use selftimer outside this range.
- When the IS/L B-28 H.Q. CONVERTER 0.8X is mounted, the remote control may not work even within the above range because the signal transmission is blocked by the converter.

When releasing the shutter from behind the camera:




Notes:

- Use the remote control from behind the camera to prevent the camera from shaking by pressing the shutter release button when in macro photography or when the tele-converter is mounted.
- When using the remote control from behind the camera, aim at the remote control sensor on the top of the grip.

Important: After the shot(s), be sure to press the selftimer/remote control button again to cancel the Remote Control mode.

■ Viewfinder Cap

Use the provided viewfinder cap to prevent light from entering the viewfinder.



Notes:

- Place the viewfinder cap securely on the viewfinder.
- When the viewfinder cap is not used, the camera may not set the correct exposure or may not focus on the subject.

Notes on the Remote Control:


- The remote control may not work when there is backlighting and when autofocusing is difficult (see p. 70).
- Continuous shooting cannot be performed when the remote control is used.
- The shutter will not release using the remote control when the remote control's battery is exhausted.
- The battery of the remote control cannot be replaced. The service life is approx. 5 years (variable with operating conditions and environments).

CAUTIONS:


- Keep the remote control out of the reach of children. In case it is swallowed, immediately consult a physician.
- Keep the remote control away from fire and extreme heat. Never try to disassemble it.

■ Bulb

1. Select the Manual Exposure mode to display **M** on the LCD panel, and set the shutter speed to **b1 b**.




2. Press the button on the remote control.



The shutter will open.

Note: The selftimer/remote control display remains on the LCD panel as long as the shutter is open.

3. Press the button on the remote control again.



The shutter will close.

Note: The shutter automatically closes when the camera's batteries are exhausted.


PRINTING THE DATE AND TIME

There are five printing modes as shown below. Choose the desired mode with the DATE MODE button.


Month mark

Print mark

Blinks for 3 seconds after the exposure to confirm that the data is imprinted.



As the DATE MODE button is pressed, the mode will switch in the order shown below.



Year-month-day

Day-hour-minute

No data

Month-day-year

Day-Month-year



The data will be imprinted when the shutter is released.

DATE MODE button:

Switches the mode.

DATE SET button:

Chooses the data to be changed.


DATE ADJUST button:

Changes the data.

CORRECTING THE DATA


Press the DATE MODE button to select the mode to be corrected.

1. Choose the data to be changed by pressing the DATA SET button. Change the data with the DATE ADJUST button.



(Make sure) The data to be corrected is blinking.

2. After setting the data, press the DATE MODE button again.



(Make sure) The print mark is displayed.

Note: For fine-tuning of the built-in clock to the beginning of a specified minute, press the DATE ADJUST button when " : " is blinking.

FLASH

Flash Strength

The flash on the IS-3DLX employs a new exposure control system that combines the advantages of both "flashmatic," used in compact cameras, and "auto flash," found in SLR cameras. Flashmatic emits a full-strength flash while automatically adjusting the aperture for proper exposure. This system is effective in most cases. However, subjects at extremely close range tend to be overexposed, and the background too dark, because the narrowest aperture setting has been selected. Auto flash varies the amount of light emitted by the flash, and sets the exposure by measuring reflected light. Depending on the background, however, the wrong exposure for the main subject can be selected. For example, with a white background, the subject may appear too dark due to the level of reflected light received through the lens. The reverse is true for a dark background.

The IS-3DLX adjusts both the aperture and flash strength to give you perfect exposure every time, taking into account the effect of the background light and the distance to the subject.

Dual-Strobe Intelligent Flash

The flash of the IS-3DLX is distinguished by two emission tubes. One of the most important functions of a flash is to distribute light evenly throughout the frame. When a zoom lens is used, the area that can be lit by a single flash is determined by the wide-angle focal length. When telephoto is used, the light

is wasted because the light is spread over a wide area. If this wasted light is concentrated on the picture area, however, the working distance of the flash will be increased. Solving this problem is crucial to effective telephoto-flash photography.

The zoom flash system found in some cameras is one solution to this problem. With this system, the distance between the xenon tube — which is the emission source of the flash — and the reflective material behind it is varied according to the focal length of the lens. When telephoto is used, the light from the flash is condensed more intensely. (The distance between the xenon tube and the condenser lens can be varied for the same result.)

So why does the IS-3DLX incorporate the dual-strobe system? Because the dual-strobe system can utilize the light more effectively while achieving more uniform lighting than the zoom flash system is capable of. The zoom flash system also cannot alter the actual shapes of the reflector and the condenser lens. In practice, these two factors greatly affect the even distribution and condensing intensity of light from the flash. The zoom flash sacrifices the effective use of the light's intensity for even distribution. To achieve both optimal condensing intensity and even distribution, Olympus developed the dual-strobe flash system with two sets of tubes and a reflective backing that are ideal for both wide-angle and telephoto photography. This makes a powerful, versatile flash with GN 28(130 100-m)/GN 92 (ISO 100-ft) possible.

The lower tube is designed for telephoto photography and offers GN 28 ~ 1.4 (ISO 100 ·m)/GN 92 ~ 4.2 (ISO 100 ·ft). The upper tube is an intelligent variable-power flash offering GN20-1.4 (ISO100 ·m)/GN 66 ~ 4.2(ISO 100·ft). When the camera-to-subject distance is less than 1.2 m in the Macro mode, the upper flash will automatically fire to prevent the flash light from being obstructed by the tip of the lens. The flash is also capable of emitting minimal intensity for ideal macro photography.

Auto-S Flash

The Auto-S Flash mode includes a series of pre-flashes that reduces the phenomenon of red-eye, in addition to the same functions as the Auto Flash mode which prevent camera-shake and insufficient lighting by automatically firing in dimly lit and dark conditions when the flash is flipped up. The phenomenon of red-eye is when subject's eyes appear red in printed photographs. In this mode, the camera will start emitting approximately 20 low-power pre-flashes about a second before the regular flash.

This contracts pupils, which are wide open in the dark, significantly reducing red-eye. The pre-flashes do not decrease the power of the main flash. The red-eye reducing effect varies according to shooting conditions.

Fill-in Flash

Fill-in refers to the auxiliary light that "fills in" areas of the subject shadowed by the main light source.

Even when the subject is backlit, the IS-3DLX can shoot it at the correct exposure using ESP metering or spot metering. However, this may wash out the background. This happens because the difference in brightness between that of the subject and the background is too great. When the Fill-in Flash is used in such a case, the subject is lit brightly by the flash. This minimizes the difference in brightness between the subject and the background, allowing both to be shot clearly. This light is also reflected from the subject's eyes (catch light effect), making the picture lively.


In this mode, the flash fires no matter what light is available as long as the flash is flipped up. (Flash emission in well-lit conditions is called daylight synchro.)

Electronic Flash G40 (Optional)


The G40 is a dedicated flash for the IS Series (GN 40, ISO 100m/GN 132, ISO 100•ft). Refer to these pages when the G40 is to be used in the Shutter-Preferred Auto mode.

■ When shooting in the Shutter-Preferred Auto mode:

1. Turn the power switch ON, set the camera's exposure mode to S.
2. Select 1/100-sec. or slower shutter speed using the shift dial.




Make sure The battery has been recharged.



Note: The G40 won't fire at shutter speeds faster than 1/100-sec.

3. Press the shutter release button.



Note: When used together, the G40 fires full emission but the built-in flash is compensated by -3EV.

Refer to the G40's manual for more instructions.

■ Advanced flash photography using the G40

Multi Flash



Normal Slow-Synchro
(Curtain-1 Synchro)



Bounce (with simultaneous use of
the built-in flash)



Follow-Synchro
(Curtain-2 Synchro)



Bounce photography uses indirect lighting of subjects by reflecting the flash off the ceiling or wall. With straight flash photography a strong shadow often appears behind the subject. By bouncing the flash, you can obtain soft, well-balanced lighting of the entire subject. You can also use the built-in flash together with the G40 for additional affects.

Multi-flash emits the light several times in one exposure. With this flash mode, continuous movement, such as a golf swing, can be photographed sequentially in one frame. It's a multiple exposure with flash.

With Follow-Synchro mode, the flash fires at the final point of slow-synchro. For example, the tail-lights of a moving automobile can be captured on film.

When the IS-3DLX is equipped with the teleconverter lens (1.7X) or the wide-converter (0.8X), the built-in flash cannot be used. We recommend you use the G40 for such cases.

EFFECTS OF ZOOM AND ITS ADVANTAGES

In a zoom lens, the focal length is changed by moving part of the lens. In the case of the IS-3DLX, any focal length between 35 mm and 180 mm can be selected.

- 35 mm wide-angle

Because the angle of view is wide and the depth of field is large, sharp photographs with enhanced perspective and contrast can be taken.

- 100 mm

With the lens zoomed to 100 mm, subjects appear three times closer than when the lens is positioned at 35 mm.

- More than 100 mm

When the lens is set to the maximum focal length of 180 mm, magnification is approximately five times greater than at 35 mm, for genuine telephoto photography. As the telephoto power is increased, the perspective narrows and the depth of field becomes more shallow. The result is that objects in front of and behind your subject are more likely to be out of focus. This can be used to interesting effect on snapshots and portraits.

Maximum telephoto lengths are particularly useful for taking pictures at sporting events and for nature photography, when you want to get closer to your subject without disturbing it.

IS/L LENS B-28 H.Q. CONVERTER 0.8X

28mm  75°



35mm  63°



100mm  24°



- The five pictures below are samples taken using the zoom lens. Notice the dimensions of the subject as the camera zooms in.

- Be sure to hold the camera firmly or use a tripod, as pictures tend to blur more easily at longer focal lengths. Setting the shutter speed at 1/250-sec. or faster is recommended.

Angle of view and depth of field



Angle of view is directly related to the focal depth of field (the distance in front of and behind the subject that the camera is able to bring into focus). The greater the angle of view (wide angle), the greater the depth of field. When the angle of view is narrow (telephoto), the depth of field decreases.

- The use of a converter lens (optional)
It is possible to attach a converter lens for an even wider angle of view, or for additional telephoto power.

Instead of 35 mm, a wide-angle converter (0.8X) enables you to reduce the camera's focal length to 28 mm.

Instead of 180 mm, a telephoto converter (1.7X) enables you to increase the camera's focal length to 300 mm.

IS/L LENS B-300 H.Q. CONVERTER 1.7X




AUTOFOCUS (AF)

■ Difficult Subjects for Autofocus to Lock Onto


Although the IS-3DLX's autofocus can lock on virtually any subject, there are certain conditions, such as ①~ ③ shown below, where it may not be possible to obtain the correct focus. In the situations shown below in ④~ ⑥, autofocus may not lock on the correct subject even though the autofocus indicator lights and the shutter releases.

① Subjects with low contrast




- Use the focus lock by first focusing on something at the same distance as the subject you wish to take a picture of, and then aim at the subject. Or use the power focus to manually focus on the subject.

② Subjects that do not contain vertical lines




- Use the focus lock first while holding the camera vertically. Then switch the camera to the horizontal position to take the photograph. Or use the power focus to manually focus on the subject.

③ Subjects in excessively bright light




- Use the focus lock by first focusing on something at the same distance as the subject you wish to take a picture of, and then aim at the subject. Or use the power focus to manually focus on the subject.

④ Two subjects at different distances




- When the subject looks out-of-focus although the autofocus lamp lights, use the power focus to manually focus on the subject.

⑤ Subjects with repetitive patterns



- When the subject looks out-of-focus although the autofocus lamp lights, use the power focus to manually focus on the subject.

⑥ High-speed subjects at close range



- Focus on another subject at the desired camera-to-subject distance first. Switch the mode to power focus, and shoot the subject when it is at the distance set in advance.

EXPOSURE

■ Automatic Exposure Mode

Exposure refers to the amount of light which strikes the film, and is controlled by a combination of aperture size and shutter speed. The correct amount of light, called correct exposure, depends on the film speed (indicated on the film package, e.g. ISO 100 or ISO 200).

The automatic exposure function automatically sets the correct exposure. The IS-3000 employs three types of automatic exposure modes: (1) programmed auto-exposure, (2) aperture-preferred auto-exposure, and (3) shutter-preferred auto-exposure.

With programmed auto exposure, the camera automatically selects the most suitable combination of F stop and shutter speed for the existing lighting conditions. This lets you concentrate on composing your shot and releasing the shutter at just the right time.

With aperture-preferred auto, you select the desired F stop, and the camera automatically selects the correct shutter speed. Aperture-preferred auto gives more artistic freedom of expression and creativity by selecting a desired F stop to control the blur of the background.

With shutter-preferred auto, you select the shutter speed, and the camera automatically selects the F stop. By changing the shutter speed, you can freeze a fast-moving subject or blur it to convey a sense of motion.


■ Program Chart (Standard Photography Mode)

The following program chart is for 35mm wide-angle and 180mm telephoto focal lengths.

According to the focal length, the camera's program itself changes. When the subject is brightly lit, the F stop and shutter speed change simultaneously.

When the lighting is darker, the aperture opens fully and the shutter speed changes to match it.

In the standard photography mode (refer to p. 14), if the built-in flash has been flipped up, it will automatically fire in dark lighting conditions. The shutter speed will be fixed at 1/100-sec.



■ Portrait Mode

In this mode, the IS-3DLX chooses a wide aperture for a short depth of field. This results in a softly blurred subject background, against which your subject stands out in sharp focus.

■ Night Scene Mode

When shooting night scenes you may sometimes be disappointed with the result, usually because the camera's automatic exposure function works on a standard exposure ratio. In such situations a professional photographer would adjust for exposure compensation based on long experience, or select the manual shooting mode.

The IS-3DLX's night scene mode will automatically adjust the exposure compensation for attractive night scene photography. For example, when shooting a subject with a night scene as its background, the use of the flash is often desirable. Should that be the case, the camera performs the most suitable exposure compensation for both the subject and the background. Since the selected shutter speed may be very slow (up to 4 seconds with ISO 100 or 15 seconds with ISO 25), the camera should be held firmly in position (with a tripod for example) to prevent blurring.

■ Sports Mode

This mode is ideal for capturing high-speed photo opportunities such as sports scenes and children at play. A fast shutter speed is automatically selected to "freeze" the action on film. However, the high shutter speed is not the only important feature of

this mode. To shoot such high-speed action, excellent timing is essential to take the photo at just the right moment. This mode offers the optimal combination of continuous shooting and autofocus to maximize your timing for maximum results.

■ Landscape Mode

This mode is ideal when you want to focus on both the subject and the background or when you want to shoot natural scenery with low contrast. The camera automatically stops down the aperture to make the range of focus as large as possible. In shooting conditions for this mode, the subjects are likely be at a distance of ∞ (infinity), so the autofocus function in this mode starts from the ∞ position.

METERING THE AMOUNT OF LIGHT

■ Light Metering

Light metering can measure the brightness of the framed picture in various ways. The IS-3DLX employs three metering systems: (1) ESP light metering, (2) center-weighted average light metering, and (3) spot metering. The IS-3DLX allows you to select the light metering system most suitable in any photographic situation.

At the same time, the IS-3DLX uses TTL (through-the-lens) light metering to automatically measure the light that enters the lens. This allows you to obtain very accurate light metering that is not affected by changes in the distance between the subject and the camera.


■ Fuzzy Logic ESP (Electro-Selective Pattern) Light Metering (Exposure Mode P)

ESP light metering measures the brightness of the central portion and peripheral portion of the frame separately in order to determine the proper exposure. The calculation program used is based on programmed data to properly compensate for backlighting. ESP light metering is used automatically when in the P (Program) mode.

■ Center-Weighted Average Light Metering (Exposure Mode A or M)

Center-weighted average light metering is the most widely used light metering system (Fig. A). This system measures the light available throughout the frame with special emphasis on the center of the frame. When in A (Aperture-preferred), S (Shutter-preferred) or M (Manual) mode, this light metering


system is automatically activated. When the contrast between bright and dark areas is not too extreme outside the center of the frame, this system offers excellent results.



■ Spot Metering

Spot metering (Fig. B) measures the brightness at the center of the frame only. Because this metering system calculates the correct exposure for only one point, it is convenient when the subject is backlit or the picture contains strong contrasts. When shooting a subject in front of an extremely bright background, you should use spot-metering on the subject's face. To properly expose white objects, use spot metering and then press the + side of the exposure compensation button. To properly expose black objects, use spot metering and then press the - side of the exposure compensation button.

Spot metering can be used in any of the P, A, S or M exposure modes.



EXPOSURE COMPENSATION

■ Fixed Proper Exposure

Proper exposure refers to the balance of light and dark in a photo. When shooting a black and white wall, the exposure will be based on the average ratio of black and white — thus the overall exposure is set for gray. This is technically called "fixed proper exposure." A good example of this is a subject with a strongly lit background. The reason the subject turns out dark is because there is more brightness than darkness in the frame. Therefore, the fixed proper exposure is based on the total level of light in the photo, which is significantly brighter than the subject. In the case of strong backlighting, the exposure needs to be adjusted to compensate for the excessive brightness.

Adjusting the exposure to accommodate lighting conditions is called exposure compensation. When ESP light metering is used, the camera automatically evaluates the lighting situation and compensates for the proper exposure, so manual exposure compensation is not needed.

■ Exposure Compensation

With the IS-3DLX, $\pm 4\text{EV}$ exposure compensation in $1/3\text{ EV}$ steps is possible. + Compensation will make a subject appear brighter, while - compensation will make a subject appear darker. Under backlit conditions you'll want to make your subject appear brighter (+1 to +2EV). For shooting winter snow scenes, you may want adjust the exposure for additional definition (+2EV). Or, suppose your picture is composed of a black wall, (-2EV) compensation would most likely be appropriate.

FILM SPEED

■ Film Speed

Film speed is indicated on the back of film packages. ISO 100, ISO 200, and ISO 400 are the most common. High-speed film (ISO 400), as implied by its name, is for taking photos of fast-moving subjects in action shots, for example. However, there are also other advantages. With high-speed film, such as ISO 400, it is possible to take pictures in lower light. And the distance covered by the flash will be greater. With this camera, we recommend the use of "DX" film cartridges: ISO 25 ~ 5000. In the case of non-DX-coded film, the camera will automatically be set to film speed ISO 32.

MACRO PHOTOGRAPHY

■ Zoom Macro

The IS-3DLX's Macro mode enables you to shoot subjects as close as 0.6 m (2 ft) when the focal length is set from 35mm to 120mm. The autofocus and built-in flash can also be used with this function, which can fill the frame with an area of approx. 12 x 18 cm (4-3/4 x 7-1/16 in) at a working distance of 0.6m (2 ft) with the focal length set to 120mm. The picture area can be adjusted by changing the focal length and working distance.

Zoom Macro at 120mm



■ IS/L LENS B- MACRO H.Q. CONVERTER f=40cm (Optional)

This is a close-up lens that lets you fill the frame with an area approx. 4.4 x 6.4 cm (1-3/4 x 2-5/8 in), about the size of an ordinary business card. This converter can be used with the Aperture-Preferred Auto Exposure mode and the Manual Flash mode. Autofocus also works when using this mode, making it ideal for macro photography beginners.

Converter f=40cm at 180mm



PANORAMA PHOTOGRAPHY (OPTIONAL)

By mounting the optional IS/L PANORAMA ADAPTER inside the camera, panorama pictures can be taken. Zoom in and out with the adapter mounted to obtain various compositions. When the optional IS/L LENS B-28 H.Q. CONVERTER 0.8X is used with the adapter, wide-angle panorama photography is possible, adding extension and depth to pictures.



Picture area is shown with panorama marks as illustrated on the left.

Panorama marks

Notes:

- When the adapter is mounted, the entire roll of film must be shot as panorama-format pictures.
- Panorama prints generally take longer to get processed than ordinary prints.
- Availability of Panorama format film processing facilities varies according to area. Consult your local film processor or camera dealer for details.

ACCESSORIES (OPTIONAL)

IS/L LENS B-300
H.Q. CONVERTER
1.7X



IS/L LENS B-28
H.Q. CONVERTER
0.8X



IS/L LENS
B-MACRO H.Q.
CONVERTER
f=40cm



Electronic Flash
G40



Grip Strap B




REMOTE CONTROL
RC-100



IS/L PANORAMA
ADAPTER



Variable Dioptic
Adapter A



CARE AND STORAGE

CAUTIONS

- DO NOT EXPOSE THE CAMERA TO EXTREME HEAT (OVER 40°C/104°F) OR TO EXTREME COLD (BELOW -10°C/14°F).
- AVOID SUDDEN TEMPERATURE CHANGES AND HUMIDITY.
- DO NOT EXPOSE THE CAMERA TO STRONG MAGNETIC FIELDS.
- DO NOT APPLY EXCESSIVE FORCE TO THE CAMERA OR ITS CONTROLS.
- DO NOT TOUCH THE CONTACT POINTS INSIDE THE CAMERA.
- DO NOT USE ORGANIC SOLVENTS, THINNERS, OR BENZINE TO CLEAN THE CAMERA.
- AVOID STRONG IMPACTS CAUSED BY BUMPING OR DROPPING THE CAMERA.
- DO NOT EXPOSE THE CAMERA TO WATER, SUCH AS FROM RAIN.
- DO NOT EXPOSE THE CAMERA TO DUST AND SAND.

WARNING

- NEVER ATTEMPT TO DISASSEMBLE THE CAMERA; IT CONTAINS A HIGH-VOLTAGE CIRCUIT.

In case of malfunction, consult your nearest Olympus dealer or Olympus service center.

BATTERY HANDLING

NOTES

- Do not mix different types of batteries or new and old batteries.
- When the camera is not used for an extended period of time, remove the batteries.
- Keep spare batteries on hand when going on a long trip or to a cold area.
- Sweat, oil, and so on can prevent a battery's terminals from making electrical contact. To avoid this, wipe both terminals before loading batteries.

WARNINGS

- NEVER TRY TO DISASSEMBLE, RECHARGE, OR SHORT CIRCUIT BATTERIES. NEVER EXPOSE BATTERIES TO EXCESSIVE HEAT OR OPEN FLAMES.
- KEEP THE BATTERIES OUT OF THE REACH OF CHILDREN. IF A CHILD SWALLOWS A BATTERY, CONTACT A DOCTOR IMMEDIATELY.
- USE TWO 3V LITHIUM BATTERIES (CR123A OR DL123A). NEVER TRY TO DISASSEMBLE OR MODIFY ANY BATTERY OR BATTERY PACK FOR USE IN THIS CAMERA.

TROUBLESHOOTING

Operating Problems

Symptom	Cause	Remedy	See
The camera does not work.	① The power is OFF. ② The batteries are loaded incorrectly. ③ The batteries are exhausted. ④ The batteries are temporarily unable to function. ⑤ The loaded film has been rewound. ⑥ The film is incorrectly loaded.	① Set the power switch to ON. ② Reload the batteries correctly. ③ Replace batteries with new ones. ④ Keep the camera warm while using it. ⑤ Load new film. ⑥ Reload the film.	p.17 p.10 p.11 p.21 p.17
The displays turn off suddenly.	① The LCD panel and viewfinder displays turn off after approx. 30 sec. (5 min. when the flash is flipped up) if the camera is not used.	① Press the shutter release button halfway to turn on the displays.	p.18
The shutter speed and aperture setting blink.	① When the light metering function of the camera does not work correctly because it's too dark, these indicators start blinking. In the Manual Exposure mode, ± also blinks.	① Use the flash.	p.26
The subject cannot be focused on.	① When the subject is moving too fast, the camera is being shaken, or the subject is difficult for autofocus to lock onto (refer to p. 70), the autofocus may not work. ② The subject is closer than the camera's minimum working distance. ③ When the PF mode is engaged, autofocus will not operate even though the shutter release button is pressed.	① Focus on the subject by using the power focus, or by first focusing on something at the same distance as the subject. ② Use the Macro mode. ③ Cancel the PF mode.	p.70 p.22 p.32 p.52

Symptom	Cause	Remedy	See
The camera doesn't focus on the subject even though the AF illuminator lights.	① The autofocus may not work when the subject is out of the AF illuminator's working distance (approx. 1.2 ~ 7 m/ 3.9 ~ 23 ft) or when the subject has low contrast (blue or black).	① Use the power focus, or move the camera closer to the subject.	p.52/70
The shutter doesn't release even when the shutter release button is pressed.	① The subject is not in focus. ② The rewound film is still loaded.	① Make sure the subject is in focus and the autofocus indicator in the viewfinder lights. ② Remove the film.	p.20 p.21
The flash doesn't fire	① The battery has not been recharged. ② The shutter speed is set at faster than 1/100-sec. (except in the Manual Exposure and Portrait modes).	① Wait until  lights. ② Set the flash mode to one other than Fill-in.	p.26 p.29
The zooming speed does not get faster even when the zoom button is fully depressed.	① As the batteries get exhausted, the fast zooming speed becomes slower, and the difference between the fast and slow zooming speeds becomes smaller.	① Check the batteries on the LCD panel. If the display blinks, replace the batteries.	p.11

Problems with Printed Pictures

Symptom	Cause	Remedy	See
The subjects' eyes appear red in printed pictures.	① This "red-eye phenomenon" occurs with all cameras when a flash is used. It is caused by light from the flash reflecting off the retina at the back of the eye. Red-eye varies depending on the individual and the shooting conditions such as ambient lighting. It is also more likely to occur when using 135mm telephoto than when using wide-angle focal lengths.	③ Use the Auto-S Flash mode to significantly reduce red-eye phenomenon.	p.28
The subject was within the frame of the viewfinder, but its edges are missing on the print.	① When a negative is enlarged, sometimes the edge of the frame is not printed.	① Leave some room on the edges of the frame when you compose your shots.	
The film is scratched.	① Sand or dust is lodged in the film path. ② Film particles have accumulated inside the camera.	① Clean the film path while taking care not to damage the shutter curtains. ② Consult your nearest Olympus dealer or Olympus service center.	
The picture is out of focus.	① The camera moved when the shutter release button was pressed. ② The viewfinder's autofocus frame was not positioned on the subject.	① Hold the camera correctly, and press the shutter release button gently. ② Position the autofocus frame on the subject, or use the focus lock.	p.12 p.22
The picture is too dark.	① The subject was out of the working range of the flash. ② The subject was backlit.	① Shoot within the working range of the flash. ② Set the flash to Fill-In mode.	p.27 p.29

QUESTIONS AND ANSWERS

Q: How long will the batteries last?

A: Two new 3V lithium batteries will last for roughly 20 rolls of 24-exposure film on which the flash was used on half of all the shots (determined under Olympus test conditions). If you do not use the flash and zoom very often, the batteries will last much longer.

Q: How should I store the camera?

A: Cameras are susceptible to damage caused by dust, moisture, and salt. Wipe and dry the camera thoroughly before storing it. After using it at the beach, wipe it with a cloth that has been moistened with fresh water and then wrung out. Do not use mothballs.

Q: When does the camera measure and set the exposure?

A: When the shutter release button is pressed halfway, the camera measures both the exposure and the focus and then locks them as long as the shutter release button remains halfway depressed. In the Spot Metering mode, the exposure is locked when the spot button is pressed.

Q: How should I clean the lens?

A: Wipe the lens gently with lens cleaning tissue that has been moistened with a small amount of lens cleaning fluid.

SPECIFICATIONS

Type: Fully automatic 35mm autofocus single-lens reflex camera with built-in 35mm ~ 180mm zoom lens.

Film format: 35mm standard DX-coded film (24 X 36mm)

Lens: Olympus lens (filter available, 55mm filter diameter) 35mm ~ 180mm F4.5 ~ 5.6, 16 elements in 15 groups (5-group zoom construction) with extraordinary dispersion (ED) glass at third element in the first zoom lens group.

Shutter: Electronic control system vertical focal plain shutter. Shutter speed 1/2000-sec. ~ 15-sec. bulb.

Focusing: TTL phase-difference detection system autofocus with focus lock, AF illuminator automatically lights up in low light. Autofocus beep available. Manual focusing available (power focus). Focusing range — 1.2 m (3.9 ft) ~ ∞; 0.6 m (2 ft) ~ ∞ in Macro mode at 35 ~ 120 mm.

Viewfinder: Single-lens reflex system, magnification ratio 0.75 (at 50mm). Finder view-field — 85% of actual view-field.

Viewfinder information: Autofocus frame, spot

frame, panorama marks, autofocus indicator, flash indicator (to be used as flash warning), shutter speed, aperture setting, spot metering, macro, exposure compensation (manual exposure).

Light metering system: TTL light metering system — Fuzzy logic ESP light metering, center-weighted average light metering, spot metering.

Exposure modes: (1) Program AE (Standard, Sports, Portrait, Night-Scene, Landscape), (2) Aperture-preferred AE, (3) Shutter-Preferred AE, (4) Manual exposure.

Exposure compensation: ±4 EV compensation possible (1/3 EV step).

Exposure counter: Progressive type, displayed on LCD panel.

Film speed range: Automatic setting with DX-coded film (ISO 25 ~ 5000).

Film loading: Automatic loading (automatically advances to first frame when camera back is closed).

Film advance: Automatic film winding, consecutive winding max. 2 frames/sec. (in PF mode, under Olympus test

conditions), double exposure possible.
 Film rewind: Automatic film rewind (automatic rewind activated at end of film, automatic rewind stop). Rewind is possible at any point with rewind button.
 Selftimer: Electronic selftimer with 12-sec. delay.
 Remote control (optional): Infrared remote control unit, 3-sec/0-sec. delay switchable).
 Flash: Built-in IVP (Intelligent Variable-Power) flash system with dual light emitting tubes. Manual activating system, recycling time of about 5 sec. (at normal temperature). Light emission, Automatic; ISO 100 · m of GN 28 / ISO 100 · ft of GN 92, Manual; ISO 100 · m of GN 20/ISO 100 · ft of GN 66
 Flash range: Wide — 1.2 ~ 6.3 m (3.9 ~ 20.7 ft), Tele — 1.2 ~ 7 m (3.9 ~ 23 ft) with ISO 100 negative color film; Wide — 1.2 ~ 12.6m (3.9~41.3 ft), Tele — 1.2 ~ 14m (3.9 ~ 45.9 ft) with ISO 400 negative color film. Flash available in Macro mode.
 Flash modes, Auto (automatic flash activation in low-light), Auto-S (red-eye reducing,

same as Auto otherwise), Fill-in (forced activation), Manual.
 Battery check: Displayed on LCD panel.
 Power source: Two 3V lithium batteries (CR123A or DL123A) (replaceable).
 Dimensions: 122(W) X 93(H) X 173(D) mm (4.8 X 3.7 X 6.8 in) (excluding protrusions).
 Weight: 960 g (33.9 oz) (without batteries).

■ DATE UNIT SPECIFICATIONS

Imprinting direction: Data imprinted from behind film in bottom left of picture.
 Data coding: Year-month-day, day-hour-minute, no data, month-day-year and day-month-year.
 External indication of data: Data display on LCD panel.
 Automatic calendar system: Up to year 2019.
 Power source: Two 3V lithium batteries (CR123A or DL123A) in camera.

Specifications are subject to change without any notice or obligation on the part of the manufacturer.

OLYMPUS®

OLYMPUS OPTICAL CO., LTD.

San-Ei Building, 22-2, Nishi Shinjuku 1-chome, Shinjuku-ku, Tokyo, Japan. Tel.03-3340-2211

OLYMPUS AMERICA INC.

Crossways Park, Woodbury, New York 11797-2087, U.S.A. Tel. 516-364-3000

OLYMPUS OPTICAL CO. (EUROPA) GMBH.

(Premises/Goods delivery) Wendenstrasse 14-16, 20097 Hamburg, Germany. Tel.040-237730

(Letters) Postfach 10 49 08, 20034 Hamburg, Germany.

OLYMPUS OPTICAL CO. (UK.) LTD.

2-8 Honduras Street, London EC1Y 0TX, United Kingdom. Tel.071-253-2772