



| Shutter speed<br>Flashbulb | 1000 | 500 | 250 | 125 | 60 | 30 | 15 | 8  | 4  | 2  | 1  | B  |
|----------------------------|------|-----|-----|-----|----|----|----|----|----|----|----|----|
| FP                         | ●    | ●   | ●   | ●   | ●  | OF | OF | OF | OF | OF | OF | OF |
| M                          | —    | —   | —   | ●   | ●  | OF | OF | OF | OF | OF | OF | OF |
| MF                         | —    | —   | —   | —   | —  | OF | OF | OF | OF | OF | OF | OF |
| X                          | —    | —   | —   | —   | FX | FX | FX | FX | FX | FX | FX | FX |



























46.5mm

Film Plane Position

























**Nikon**

SB-700






















**YUASA**

SEALED  
TIGHT  
BATTERY



**YUASA**

SEALED  
TIGHT  
BATTERY



**YUASA**

SEALED  
TIGHT  
BATTERY













# SHUTTER SPEED RANGE

(1/1000 sec)

| Shutter Speed | Exposure Time | Shutter |
|---------------|---------------|---------|
| 1/1000        | 1/1000        | 1/1000  |
| 1/500         | 1/500         | 1/500   |
| 1/250         | 1/250         | 1/250   |
| 1/125         | 1/125         | 1/125   |
| 1/60          | 1/60          | 1/60    |
| 1/30          | 1/30          | 1/30    |
| 1/15          | 1/15          | 1/15    |
| 1/8           | 1/8           | 1/8     |
| 1/4           | 1/4           | 1/4     |
| 1/2           | 1/2           | 1/2     |
| 1             | 1             | 1       |


1/1000 to 1/4 sec. and 1/2 sec.

Nikon

MADE IN JAPAN

1/1000







Nikon

MADE IN JAPAN

• 101342









**Extension Ring E2**





K Ring



E2 Ring



# SHUTTER SPEED RANGE

(12 VOLTS)

| Shooting Speed<br>(Approx.)<br>Frames / sec. | Consecutive Exposures |                |                |          | Single<br>Exposure |
|----------------------------------------------|-----------------------|----------------|----------------|----------|--------------------|
|                                              | L                     | M <sub>1</sub> | M <sub>2</sub> | H        |                    |
|                                              | 2                     | 2.5            | 3              | 4        |                    |
| Mirror Coupled                               | 8-1000                | 60-1000        | 125-1000       | Not Used | B, 1-1000          |
| Mirror Raised                                | 8-1000                | 30-1000        | 30-1000        | 125-1000 | B, 1-1000          |

\* (B): To be used at 9 volts

Nikon

JAPAN











BR-5



BR-6








PB-4



PB-5










PS-5

PB-5



PS-4


PB-4











No. 0

No. 1

No. 2


No. 3T

No. 4T

No. 5T

No. 6T




















**Electronic Ring Flash**

**Combination of  
Auxiliary lenses**

**Power source socket**

**Signal neon lamp**

**Printed figure  
brightness adjustment**

**Figure to be printed**


**Aperture scale**

**Reproduction scale**


**Film Speed  
ASA scale**



































AN-6W



AN-6Y



AN-4Y



AN-4B



AN-1



