




















Calculator Panel on Rear Section

1




T32



T20









Motor Drive 1



Winder 2































































FLASH PHOTOGRAPHY SYSTEM CHART














OLYMPUS

FE 300
QUICK


















Terminal Contacts

**Grip
Detach
Button**

**Grip
Lock
(2)**

**Mounting
Catch
(Red Index**


**Mode
Selector**

**Release
Lock
Lever**

**Non-Slip
Knot (Rear**

**Shutter
Release**


**Non-Slip
Knot (Front)**
















































Kodacolor I


135 mm film color negative


135-36












































Camera Back Locking catch

Film Pressure springs


1

6


7


Film Anti curl roller

Film Pressure plate












Cross-section
of film
advance

(●: Ball bearings)



(2)

