


Repair and Support System

F4/F4S



Nikon | NIKON CORPORATION
Tokyo, Japan

August 1989
Printed in Japan

F4 TROUBLE DIAGNOSTIC SYSTEM

1. The difference between the Trouble Diagnostic Systems for the F-401 (N4004) and F-801 (N8008), and that for the F4 is as follows:

The usage of the F4 Trouble Diagnostic System is totally different from that of the F-401 (N4004) and the F-801 (N8008).

In the Trouble Diagnostic System for the F-401 (N4004) and the F-801 (N8008), trouble diagnostic procedures and inspections based on communications have been included in the program file on the floppy disk provided. While in the Trouble Diagnostic System for the F4, the program file on the floppy for the previous models has been divided into following two forms:

Configuration of the F4 Trouble Diagnostic System

Item	Medium	Contents
(1) F4 check flowchart	Paper material	Trouble diagnostic procedures
(2) F4 Trouble Diagnostic System	Floppy disk	Inspections based on communications: 1. Sequence errors 2. Film advance mode 3. Reading out EEPROM data 4. Exposure data 5. Checking of each motor driving 6. Block operations

2. Usage of the F4 Trouble Diagnostic System
 - (1) Usually you will find pertinent items from the Trouble Diagnostic Check Flowchart in the first place. The Trouble Diagnostic Program is used only when inspection based on communication between personal computer and F4 camera is carried out. Inspection based on communication between computer and camera will be explained in the Trouble Diagnostic Check Flowchart.
 - (2) The F4 Trouble Diagnostic System has been designed to find out the cause of trouble found in the F4 body. Accordingly, nothing has been discussed on the trouble caused by accessories (viewfinder, data back, battery pack, etc.) in this system.

For instance, when receiving F4S (MB-21 attached) camera for repair, check to see first of all if the trouble is found in the MB-21 or not. Then utilize the F4 Trouble Diagnostic System.

F4/F4S
TROUBLE DIAGNOSTIC
CHECK FLOWCHART

CONTENTS

Item	No.	Phenomenon	Page
A.		Name and location of each press contact.	A1
B.		Malfunction of shutter prerelease operation	
	B-1:	Shutter prerelease operation does not work.	B1
	B-2:	Shutter prerelease timer is not turned OFF.	B3
	B-3:	Shutter prerelease timer is not turned OFF. Exposure value does not change.	B5
	B-4:	Shutter prerelease timer is not turned OFF, Malfunction of AF indicators.	B5
	B-5:	Shutter prerelease timer always holds for 0 second.	B6
	B-6:	Shutter can be released when shutter prerelease switch is ON.	B6
	B-7:	Shutter can be released continuously when shutter prerelease switch is ON.	B6
C.		Malfunction of shutter release operation	
	C-1:	Shutter cannot be released.	C1
	C-2:	Shutter cannot be released when film is not loaded and camera back is closed.	C2
	C-3:	Shutter can be released while camera back is open.	C2
	C-4:	Shutter is released when power (battery) is turned ON.	C2
D.		Malfunction of sequence operation	
	D-1:	Sequence error.	D1
	D-1-1:	ERROR DATA (128). Voltage of DC-DC converter is lower than guaranteed value.	D2
	D-1-2:	ERROR DATA (64). Sequence error of rear shutter curtain.	D3
	D-1-3:	ERROR DATA (32). Main CPU hang-up. (Microprocessor is dead.)	D5
	D-1-4:	ERROR DATA (8). Mechanical charging error.	D5

G-12:	Shutter speed remains at 1/250(X) sec.	G8
G-13:	Metering accuracy is incorrect.	G9
G-14:	Metering value is incorrect.	G10
G-15:	Aperture value (F-Fo) is incorrect.	G10
G-16:	Full aperture value (Fo) is incorrect.	G10
G-17:	Film speed value is incorrect.	G11
G-18:	DX-coded value is incorrect.	G11
G-19:	Exposure compensation value is incorrect.	G12
G-20:	AE-L button is defective.	G12
G-21:	Always in minimum aperture value.	G13
G-22:	Always in full aperture value.	G15
G-23:	Aperture control is unstable.	G15
G-24:	Exposure value of aperture and shutter speed controls differ by 1EV or more.	G15

H. Malfunction of AF operation

H-1:	Focus aid operation is unable.(Focus indicators do not appear.)	H1
H-2:	AF lens does not operate.	H2
H-3:	Unstable AF lens operation.	H3
H-4:	AF lens performs scanning operation only when shutter prerelease switch is ON.	H3
H-5:	Subject is not in focus on focusing screen though in-focus indicator appears.	H4
H-6:	List of trouble due to disconnection of lens contacts (7 portions).	H5

I. Malfunction of display


I-1:	Malfunction of LCD and LED displays at body side.	I1
I-2:	Malfunction of focus indicators.	I2
I-3:	Malfunction of exposure compensation indicator.	I3
I-4:	List of trouble due to poor press contact between main FPC and display FPC.	I4


1. 圧接部の名称について Name and location of each press contact.



F4ボディの各圧接部の名称は、F4故障診断チェックフローチャート中では以下のように表しています。
(各FPC、ユニットごとに色付けをするとより各部が判り易くなります。)



A name of each press contact of F4 body is expressing as follows in F4 repair and support flow chart.

(Every part becomes easy to understand by applying a color every each FPC and a unit.)












Shutter speed dial base plate FPC

T7' 基板 FPC



	Phenomenon	Cause
B-1	Shutter prerelease operation does not work. (No display appears and camera does not operate when shutter prerelease switch is ON.)	1. Contamination is present in shutter prerelease switch. Soldered portion in shutter prerelease switch is detached. 2. Cord (blue) is pinched. (Short-circuit to the body) 3. Soldered portion in battery contacts is detached. 4. Contamination is present in brush of S-C dial. 5. DC-DC converter is defective. 6. Main FPC


** Check to see if there is short-circuit in the circuits by connecting a DC regulated power supply to the camera before starting trouble diagnostic operation.



a

Raise S-C dial.

[Inspection of soldered portion of battery contacts and main FPC]
Try to solder battery contacts again.




*Soldered portion of battery contacts is defective.

LCD display appears.

LCD display does not appear.

Remove front body.

[Inspection of DC-DC converter]
Remove five cords (red, black, yellow, brown, orange) of DC-DC converter from main FPC and connect them as follows.



Measure voltage of brown cord (5.5V) and orange cord (12V) with a voltmeter.

*DC-DC converter is defective.

Voltage (5.5V, 12V) is not output.

Voltage (5.5V, 12V) is output.

*Main FPC is defective.

	Phenomenon	Cause
B-2	Shutter prerelease timer is not turned OFF.	1. Short-circuit in shutter prerelease switch. 2. Short-circuit in cable release switch. 3. Short-circuit between DC-DC converter cord (yellow) and GND. 4. Main FPC is defective.




Fig. b-2-1







Fig. b-2-2

	Phenomenon	Cause
B-3	Shutter prerelease timer is not turned OFF. Exposure value does not change. For example: Shutter speed does not change even when the subject is in bright or dark environment if exposure mode selector is set to A and aperture dial is set to f5.6.	1. Main FPC is defective. 2. Lock encoder FPC is defective. 3. AE lock switch remains ON.



	Phenomenon	Cause
B-4	Shutter prerelease timer is not turned OFF. Malfunction of AF indicators. For example: AF indicators does not appear in AF-S and AF-C modes, and AF indicators appear in AF-M mode.	1. Main FPC is defective. 2. Lock encoder FPC is defective. 3. AF lock switch remains ON.



	Phenomenon	Cause
B-5	Shutter prerelease timer always holds for 0 seconds.	1. Battery power for customer's camera is insufficient. (Power has been exhausted.) 2. Main FPC is defective. 3. AF base plate is defective. 4. Screw on battery contact base plate is missing.





Fig. b-5-1

	Phenomenon	Cause
B-6	Shutter can be released when shutter prerelease switch is ON.	1. Short-circuit between shutter prerelease switch and shutter release switch.

	Phenomenon	Cause
B-7	Shutter can be released continuously when shutter prerelease switch is ON. (Shutter curtain does not open, film is not advanced.)	1. Shutter release Mg. mechanism does not work properly or shutter release Mg. is defective. 2. Malfunction of shutter release vertical shaft operation. 3. Malfunction of shutter release mechanism on film advance base plate. 4. Main FPC is defective.

	Phenomenon	Cause
C-1	Shutter cannot be released.	1. Trouble due to abnormal operation found in other items. 2. Main FPC is defective.





Fig. c-1-1

	Phenomenon	Cause
C-2	Shutter cannot be released when film is not loaded and camera back is closed. Alert LED lights up (film advance error) and generates rattling sound (when shutter is released. Both shutter release and film advance operations work properly when camera back is closed and film is loaded. But if film rewind operation is performed, film rewind operation remains not to stop.	1. Film detection switch is open.

	Phenomenon	Cause
C-3	Shutter can be released while camera back is open.	1. Camera back remains opened. 2. Frame counter switch remains OFF. (LCD frame count does not return to 0.)

	Phenomenon	Cause
C-4	Shutter is released when power (battery) is turned ON.	1. Short-circuit between gray cord of cable release switch and GND. 2. Short-circuit between shutter release switch and GND.

The following are actual phenomenon of trouble attributable to above two causes.

(1) Film advance and shutter release.

Film advance modes:

In CH, CL or CS mode, shutter release operation goes on continuously in each mode when power is switched ON. (Shutter release operation does not stop.) In S or self-timer mode, shutter is released once in each mode. Following shutter release operation cannot be performed unless power is turned OFF once.

Auto film loading: Shutter cannot be released after film is loaded using auto film loading mode. Turn power OFF once to perform the above mentioned operation.


(2) Shutter control: Normal

(3) Shutter prerelease timer: It does not turn OFF.

	Phenomenon	Cause
D-1	Sequence error	You can perform Trouble Diagnostic operation in either one of the following two methods. 1. You can check sequence error by using Trouble Diagnostic Program and find out the cause of the trouble. 2. Read out values written in EEPROM (address 30) using adjustment program and proceed trouble diagnostic operation by referring the contents to be mentioned in the following pages.


**Be sure to rewrite the data written in EEPROM (address 30) to "0" before you return camera to customer.


	Phenomenon	Cause
D-1-1	Voltage of DC-DC converter is lower than guaranteed value. EEPROM (30) -> ERROR DATA (128)	1. Battery power for customer's camera is insufficient. (Power has been exhausted.) 2. Film advance and rewind mechanisms do not work properly.



	Phenomenon	Cause
D-1-2	Sequence error of rear shutter curtain. EEPROM (30) -> ERROR DATA (64). *Sequence error warning appears. (Alert LED blinks.)	1. Poor contact of press contact (D) 2. Shutter is defective. 3. Shutter release Mg. is defective. 4. Main FPC is defective.


Note: Rear curtain and mechanical charging switches are inserted in parallel to circuit.






How to set shutter to "charging state."
Method 1: Rotate the charging cam up to charging completion position by raising shutter speed dial base plate after removing screws.

Method 2: Apply 3V power on mechanical charging motor (yellow, black cords).




	Phenomenon	Cause
D-1-3	Main CPU hang-up. (Microprocessor is dead.) EEPROM (30) -> ERROR DATA(32).	No cause of this trouble is known since this trouble has ever been occurred by now. Send Nikon detailed report on customer's specifics such as: *Location of shooting, *Type of film loaded, *Type of battery installed, *Accessories used, *Environment when trouble occurred (ex. in shutter release operation, in film advance or film rewinding operation, and others).

	Phenomenon	Cause
D-1-4	Mechanical charging error. EEPROM (30) -> ERROR DATA (8). *Sequence error warning appears. (Alert LED blinks)	1. Mechanism in film advance base plate is defective. 2. Poor press contact (A) 3. Power transistor FPC is defective. 4. Main FPC is defective.



	Phenomenon	Cause
D-1-5	X close error. EEPROM (30) -> ERROR DATA (4) *Sequence error warning appears. (Alert LED blinks.)	1. Shutter unit is defective.

Note: X close error does not occur with back body alone. (Data cannot be written in EEPROM.)



	Phenomenon	Cause
D-1-6	No expected aperture pulse is output. EEPROM (30) -> ERROR DATA (2) *Sequence error warning does not appear.	1. Aperture P.I gear spring tension is insufficient. 2. Poor contact of press contact (B). 3. Poor soldering of aperture P.I. 4. Aperture P.I. is defective. 5. Mechanical operation of mirror box I base plate is improper. 6. 3.4 lever (aperture lever) is bent.

	Phenomenon	Cause
D-1-7	Aperture stop down error. EEPROM (30) -> ERROR DATA (1) *Sequence error warning appears. (Alert LED blinks.)	1. Aperture P.I. gear spring tension is insufficient. 2. Poor soldering of aperture P.I. 3. Mechanical operation of mirror box I base plate is improper.

	Phenomenon	Cause
D-2	Mirror does not move up completely. Shutter curtain does not open. Camera goes into sequence error. Rear curtain sequence error EEPROM (30) -> 64	1. Poor contact of press contact (D). 2. Charging switch is not turned ON. 3. Disconnection of shutter speed dial FPC. 4. Main FPC is defective.

Remove top cover at film advance side.

[Inspection of charging switch]
Check to see if mechanical charging operation stops or not when shutter prerelease switch is ON and land of charging switch cord (gray) is short-circuited to GND. Refer to Fig. d-2-1.

It does not stop.

*Charging switch is not turned ON. Contamination is present. Soldered portion is detached.

It stops.

Charging switch (gray)




Fig. d-2-1

Remove front body.

[Inspection of press contact (D), main FPC]
Clean press contact (D), and check operation after reassembling.

Operation is normal.

*Poor contact of press contact (D).

Operation is abnormal.

[Inspection of shutter speed dial FPC]
Check continuity of charging switch line. Refer to Fig. d-2-2.

No continuity.

*Disconnection of shutter speed dial FPC

Continuity






Fig. d-2-2


*Main FPC is defective.

	Phenomenon	Cause
D-3	Mechanical charging does not stop. (Mirror does not move, shutter does not open.)	1. Charging switch is defective. 2. Shutter is defective. 3. Mechanical operation of film advance base plate is improper. 4. Power transistor FPC is defective. 5. Main FPC is defective.





	Phenomenon	Cause
D-4	AF filter remains operating when shutter prerelease switch is ON or film rewind motor remains operating.	1. Film rewind vertical shaft gear is damaged. 2. Operation of AF filter change over driving base plate is improper. 3. Poor contact of AF filter switch. 4. Poor contact of AF connector. 5. AF base plate is defective.



	Phenomenon	Cause
D-5	Operation stops when mirror moves up. Shutter prerelease switch cannot be turned ON afterward (or power cannot be ON).	1. Oscillator is defective. (8MHz oscillator for main CPU)

	Phenomenon	Cause
E-1	Preliminary film advance does not work.	1. Poor contact of frame counter switch 2. Poor contact of camera back switch

[Inspection of frame counter switch] (Phenomenon occurred when frame counter switch is open.) Ordinary shutter release operation and film advance operation are carried out normally, through preliminary film advance and auto film loading operations do not work. But frame counter in viewfinder does not return to "0" when camera back is opened after film rewind operation is completed. When shutter prerelease switch is turned ON after pushing film detection lever while camera back is open, a spool rotates for approx. one second and alert LED (End of roll indicator) lights up. (Film advance error.)

Yes

*Frame counter switch is open.

No

[Inspection of camera back switch] (Phenomenon occurred when camera back is open.) Shutter can be released while camera back is open. When shutter release switch is turned ON after pushing film detection lever while camera back is open, alert LED (end of roll indicator) lights up generating mechanical charging sound. (Film advance error.)

Yes

*Camera back switch is open.

No

E-4 Spool motor does not rotate. Refer to page E3.

	Phenomenon	Cause
E-2	Auto film loading does not work.	1. Poor contact of frame counter switch.

[Inspection of frame counter switch] (Phenomenon occurred when frame counter switch is open.) Ordinary shutter release operation and film advance operation are carried out normally, though preliminary film advance and auto film loading operations do not work. But frame counter in viewfinder does not return to "0" when camera back is opened after film rewind operation is completed. When shutter prerelease switch is turned ON after pushing film detection lever while camera back is open, a spool rotates for approx. one second and alert LED (end of roll indicator) lights up. (Film advance error.)


Yes

*Frame counter switch is open.

No

E-4 Spool motor does not rotate. Refer to page E3.


	Phenomenon	Cause
E-3	Film advance error. (End of roll indicator (red LED) lights up.)	1. Poor contact of frame counter switch. 2. Poor contact of camera back switch.



	Phenomenon	Cause
E-4	Spool motor does not rotate.	1. Poor contact of AF connector. 2. Poor contact of film advance completion switch. 3. Poor contact of press contact (D) 4. Power transistor FPC is defective. 5. Main FPC is defective. 6. AF FPC is defective.

Make inspection in the order of [A:*] ~ [D:***] in case of the trouble "Spool motor does not rotate."

[A: Inspection of AF connector]



[B: Inspection of film advance completion switch]

[Inspection of film advance completion switch]
*With a personal computer: it is possible to ON/OFF inspection of film advance completion switch using adjustment program.







Fig. e-4-1

[C: Inspection of power transistor FPC, spool motor]



[D: Inspection of Film detection switch]



[E: Inspection of main FPC]

[Inspection of main FPC spool motor driving output]
Set camera back switch OFF or set frame counter "1" or more, measure voltage between P1 and GND of main FPC while shutter release switch is ON.
Correct value:
5.5V (shutter release switch is OFF.)
0V (after shutter release switch is ON)
Refer to Fig. e-4-5.

Remains 5.5V.

*Main FPC is defective.

Normal

Check again carefully to see if you have missed the inspection.






Fig. e-4-5

	Phenomenon	Cause
F-1	Film is not rewound automatically.	1. Damage of film rewind vertical shaft gear. 2. Poor contact of press contact (D). 3. Poor contact of R1 switch. 4. Poor contact of R2 switch. 5. Shutter speed dial base plate is defective. (Shutter speed dial FPC is disconnected.) 6. Power transistor FPC is defective. 7. Main FPC is defective.








Fig. f-1-2

	Phenomenon	Cause
G-1	Exposure control is abnormal.	1. Poor contact of press contact (D). 2. Shutter speed dial base plate is defective. 3. Main FPC is defective.










Fig. g-1-1







	Phenomenon	Cause
G-2	Shutter speed setting is unstable.	1. Shutter is defective. 2. 3. 4.


	Phenomenon	Cause
G-3	No adjustment of high shutter speed accuracy (1/8000, 1/4000 sec.) is possible.	1. Shutter is defective. 2. Data on EEPROM (11) is incorrect. 3. 4.

	Phenomenon	Cause
G-4	Shutter curtain does not open sometimes.	1. Shutter is defective. 2. 3. 4.

	Phenomenon	Cause
G-5	Shutter curtain does not open.	1. Shutter is defective. 2. Poor press contact (D) 3. Main FPC is defective. 4.

*If the same trouble occurs even when shutter is replaced (press contact (D) is cleaned), main FPC is defective.

	Phenomenon	Cause
G-6	Shutter bound.	1. Shutter is defective. 2. 3.

	Phenomenon	Cause
G-7	Shade appears on frame (upper part). Film cartridge side.  Spool side.	1. Shutter is defective.

Notes on suffix:

E, F:


No measures have been taken. (It is possible that rear curtain does not return or focusing screen is shaded.)

G, H, JH, JHG, ...L:

Measures have been taken temporary. It is less possible that rear curtain does not return or focusing screen is shaded. If it occurs, send the defective shutter back to Nikon with a reporting sheet.)

K, and after:


Measures have been taken. (If trouble has occurred, send defective shutter back to Nikon with a reporting sheet.)

	Phenomenon	Cause
G-8	Shade appears on frame, underexposure (lower part). Film cartridge side  Spool side	1. Charging cam is defective.


	Phenomenon	Cause
G-9	All shutter speeds of 1/125 sec. or higher are set to 1/60 sec.	1. Shutter is defective. 2. Poor press contact (D) 3. Main FPC is defective. 4.

	Phenomenon	Cause
G-10	Some of shutter speeds on dial do not change when shutter speed dial is rotated.	1. Shutter speed dial base plate is defective. 2. Poor press contact (D) 3. Main FPC is defective. 4.

	Phenomenon	Cause
G-11	Shutter speed remains at 1/8000 sec.	1. Poor press contact (D) 2. Shutter speed dial base plate is defective. 3. Main FPC is defective. 4.




	Phenomenon	Cause
G-12	Shutter speed remains at 1/250 (X) sec.	1. Shutter speed dial base plate is defective. 2. Poor press contact (D) 3. Main FPC is defective. 4.




	Phenomenon	Cause
G-13	Metering accuracy is incorrect. *Only spot metering accuracy is incorrect.	1. Main FPC is defective. 2. 3.

Example: Exposure display shows 1/250 sec. though shutter speed dial shows 1/30 sec.




	Phenomenon	Cause
G-14	Metering value is incorrect.	1. Main FPC is defective. 2.

	Phenomenon	Cause
G-15	Aperture value (F-Fo) is incorrect.	1. F-Fo base plate is defective. 2. Poor contact of F-Fo pulley (brush). 3. Main FPC is defective.




	Phenomenon	Cause
G-16	Full aperture value (Fo) is incorrect.	1. Fo base plate is defective. 2. Poor contact of Fo brush





	Phenomenon	Cause
G-17	Film speed value is incorrect.	1. Poor contact of film speed dial brush. 2. Short-circuit or disconnection of circuit patterns in film speed dial. 3. Main FPC is defective.


	Phenomenon	Cause
G-18	DX-coded value is incorrect.	1. Poor contact of DX pins. 2. Poor contact between DX pins and DX FPC. 3. Film cartridge is defective. 4. Poor press contact (E). 5. Main FPC is defective.




	Phenomenon	Cause
G-19	Exposure compensation value is incorrect.	1. Shutter speed dial base plate is defective. 2. Poor contact of press contact (D). 3. Main FPC is defective.



	Phenomenon	Cause
G-20	AE-L button is defective.	1. Lock encoder FPC is defective. 2. AE-L switch is defective. 3. Main FPC is defective.




	Phenomenon	Cause
G-21	Always in minimum aperture value.	1. Poor contact of AF connector. 2. Poor contact of press contact (B). 3. Aperture P.I is defective. 4. Aperture Mg. is defective. 5. Tension of aperture gear speed-up spring is defective. 6. Mirror box mechanism is defective. 7. Main FPC is defective.



a

[Inspection of aperture Mg. ON signal]
Check to see if aperture Mg. ON signal is output after shutter release operation using oscilloscope.




No signal is output.

*Main FPC is defective.

Signal is output.

[Inspection of aperture Mg. ON operation]
Check to see if "click" sound can be heard when collector of Q5 is short-circuited to GND (diecast) while shutter prerelease timer is ON.



No sound can be heard.

*Aperture Mg. is defective.

Sound can be heard.

[Inspection of mirror box mechanism]
Mount lens on camera, and check to see if lens aperture is in full aperture when shutter is released while release switch is ON in the same conditions (aperture Mg is being operated) as mentioned above [Inspection of aperture Mg. operation].

Not in full aperture.

*Mirror box mechanism is defective.

In full aperture.


*Tension of aperture speed-up gear spring is defective. (270° normally).

	Phenomenon	Cause
G-22	Always in full aperture value.	1. Poor contact of AF connector. 2. Mirror box mechanism is defective. 3. Aperture Mg. is defective. 4.


	Phenomenon	Cause
G-23	Aperture control is unstable.	1. Poor contact of AF connector. 2. Mirror box mechanism is defective. 3. Poor soldering of aperture P.I. 4.

	Phenomenon	Cause
G-24	Exposure value of aperture and shutter speed controls differ by 1EV or more.	1. Tension of aperture speed-up gear spring is defective. 2. 3. 4.


	Phenomenon	Cause
H-1	Focus aid operation is unable. (Focus indicators x▶●◀ do not appear.)	1. Poor contact of AF connector or it is contaminated. 2. Disconnection or detachment of soldering of orange cord. 3. AF base plate is defective. 4. DC-DC converter is defective. 5. Main FPC is defective.



	Phenomenon	Cause
H-2	AF lens does not operate.	1. AF base plate is defective. 2. AF driving portion (including AF motor.) is defective. 3. Main FPC is defective.



	Phenomenon	Cause
H-3	Unstable AF lens operation.	1. Foreign matter is present on AF filter or AF sensor. 2. Poor soldering of AF PI. Operation of AF PI mechanism is improper. 3. AF base plate is defective.




Note: The way of AF operation may vary depending on the size or location of foreign matter.
 Example: When a relatively large piece of foreign matter is present on the AF filter, the lens may operate little by little and come into focus.


	Phenomenon	Cause
H-4	AF lens performs scanning operation only when shutter prerelease switch is ON.	1. Foreign matter is present on AF filter or AF sensor. 2. Poor soldering of AF.PI. Mechanical operation of AF.PI is improper. 3. AF base plate is defective.

AF scanning operation:
 Usually AF lens moves from infinity to near and near to infinity once immediately after shutter prerelease switch is turned ON when nothing has been detected on AF sensor (or not in focus).

	Phenomenon	Cause
H-5	Subject is not in focus on focusing screen though in-focus indicator appears.	1. Foreign matter is present on AF filter or AF sensor. 2. Angle of 45° between main and sub mirrors is incorrect. 3. Body back is defective. 4. AF adjustment is improper. 5. Customer's lens is defective.




H-6	List of trouble due to disconnection of lens contacts (7portions).
-----	--




Terminal No.	Terminal name	Phenomenon (AF lens)		Phenomenon (AF lens for F3)
A	VCC	Focus aid is possible. AF does not work. No communication with flash.	Does not change to "P" and "S" modes. (Remains in "A" mode.)	Does not work.
B	RW1	Focus aid is possible. AF does not work. No communication with flash.	Does not change to "P" and "S" modes. (Remains in "A" mode.)	No trouble can be detected.
C	CLK (Wide -> Tele)	Focus aid is possible. AF does not work. No communication with flash.	Does not change to "P" and "S" modes. (Remains in "A" mode.)	In Wide -> Tele mode, lens moves but does not focus. In Tele -> Wide mode, lens does not move. Focus aid is possible.
D	SI/O (Tele -> Wide)	Focus aid is possible. AF does not work. No communication with flash.	Does not change to "P" and "S" modes. (Remains in "A" mode.)	In Tele -> Wide mode, lens moves but does not focus. In Wide -> Tele mode, lens does not move. Focus aid is possible.
E	RW2	No trouble can be detected.		Does not work.
F	VCC (relative distance)	No trouble can be detected.		Does not work.
G	GND	Focus aid is possible. AF does not work. No communication with flash.	Does not change to "P" and "S" modes. (Remains in "A" mode.)	Does not work.

	Phenomenon	Cause
I-1	Malfunction of LCD and LED displays at body side. This corresponds to the trouble in display at body side only. Find cause of trouble using each check flow when metering and AF accuracy operations are abnormal.	1. Poor contact of press contact (F). 2. Display FPC is defective. 3. Main FPC is defective. 4.




Note 1: Take special care for handling connector used in old type of display press contact for it is very sensitive. Replace old type of connector with new one as much as possible.

	Phenomenon	Cause
I-2	Malfunction of LED focus indicators. (No indicator appears, or indicators flicker.)	1. Poor contact of press contact (F) in display FPC. 2. Poor contact of AF connector. 3. AF base plate is defective. 4. Main FPC is defective.



	Phenomenon	Cause
I-3	Malfunction of exposure compensation indicator (+/-). It does not light up. It remains lit It lights up but is unstable.	1. Poor contact of press contact (F). 2. Poor contact of press contact (D). 3. Shutter speed dial base plate is defective. 4. Display FPC is defective. 5. Main FPC is defective.

If LED lights up due to gap of exposure compensation dial at position 0, replace the dial.



I-4	List of trouble due to poor press contact between main FPC and display FPC. Conditions: Lens; AF50mm f/1.4, with no viewfinder, and illuminator switch being ON. Replace old type of press contact with new one as much as possible.
-----	--

Display at body side.		Name of land of press contact.	
		1: LCD, 3V 2: SB.STBY1 3: DISPLAY. OFF 4: LCD.RST 5: LC.I/O2 6: LCD.CLK2 7: LCD.I/O2 8: LCD.5V 9: LCD.GND	
LCD display	LED display		
*LCD display with no viewfinder mounted.	*AF indicator		
*Illuminator	*Exposure compensation display		
	*Flash ready-light display		

Phenomenon when each land at press contact becomes disconnected (open).						
	LCD display	LED display	Illuminator	Shutter release	AF operation	Others
1: LCD.3V	Normal	No display appears.	Does not light up.	Normal	Normal	
2: SB.STBY1	Normal	Normal	Normal	Normal	Normal	Not applicable without viewfinder and flash.
3: DISPLAY OFF	Display does not go out when mirror moves up.	Display does not go out when mirror moves up.	Does not go out when mirror moves up.	Normal	Normal	
4: LCD.RST	No display appears.	No display appears.	Does not light up.	Normal	Normal	
5: LC.I/O2	No display appears.	No display appears.	Does not light up.	Normal	Normal	
6: LCD.CLK2	No display appears.	No display appears.	Does not light up.	Normal	Normal	
7: LCD.I/O2	Both LCD/LED and illuminator light up but unstable and flicker.			Normal	Normal	
8: LCD.5V	No display appears.	No display appears.	Does not light up.	Normal	Normal	
9: LCD.GND	No display appears.	No display appears.	Does not light up.	Normal	Normal	

*In case of short-circuit between each land of press contact and next land.						
	LCD display	LED display	Illuminator	Release	AF operation	Others
1: LCD.3V - SB.STBY1	Normal	Normal	Normal	Normal	Normal	Normal without viewfinder and flash.
2: SB.STBY1 - DISPLAY OFF	Normal prior to shutter release operation. After shutter release operation, mirror moves up and ready-light LED lights up.			Normal	Normal	
3: DISPLAY OFF - LCD.RST	Normal prior to shutter release operation. After shutter release operation, display and illuminator go out and shutter release operation become impossible.			Impossible	Normal	
4: LCD.RST - LC.I/02	No display appears.	No display appears.	Does not light up.	Impossible	Impossible	Power is applied and holds for 16 seconds.
5: LC.I/02 - LCD.CLK2	No display appears.	No display appears.	Does not light up.	Normal	Normal	
6: LCD.CLK2 - LCD.I/02	No display appears.	No display appears.	Does not light up.	Normal	Normal	
7: LCD.I/02 - LCD.5V	Both LCD and LED display light up. (All segments of LCD and LED light up.)			Normal	Normal	
8: LCD.5V - LCD.GND	No display appears.	No display appears.	Does not light up.	Impossible	Impossible	Current flows instantly when shutter prerelease switch is turned ON, but it does not hold for 16 seconds.

	Phenomenon	Cause
L-1	Flash does not fire when using sync terminal.	1. Shutter (sync contact) is defective. 2. Poor press contact (C). 3. Triac base plate is defective. 4. Main FPC is defective.

Does it fire when flash is mounted on accessory shoe of DP-20?


It does not fire.

It fires.

*Sync terminal is defective.
 *Sync terminal contact spring is detached or contaminated.
 *Soldering of green cord of triac base plate is detached.

Remove front cover.

[Inspection of sync contact of shutter]



Measure terminal voltage of blue cord while setting shutter speed dial to "B".

Correct value:

3.3V (prior to shutter release operation)

0V (after shutter release operation)

Terminal voltage does not become 0V.

*Shutter is defective.

Terminal voltage becomes 0V after shutter release operation.


[Inspection of press contact (C)]
Clean press contact (C), and check to see if flash fires when flash is connected to sync terminal after reassembling.

Normal


*Poor contact of press contact (C).

Abnormal

a



[Inspection of triac base plate] can be performed by attaching triac base plate (correct parts) externally as shown in the figure below and check flash firing.



Make sure that there are old and new combinations in main FPC and triac base plate. Refer to Technical Information bulletin (Ref. No.: F4-890026).

If you mounted old and new combinations reversely (without making any corrective measures), the following trouble occurs.

1. Old FPC + New triac base plate

Current flow display (250mA) does not appear when shutter prerelease switch is turned ON. Shutter can not be released.

2. New FPC + Old triac base plate


Rear curtain sync flash even in T (time) mode (with SB-24 mounted.)

Z-1	List of trouble due to disconnection of each pin of 24-pin AF connector. Conditions: DP-20 and AF50 F/1.4 lens are mounted.
-----	---

No.	Land name	Phenomenon
1.	AF-GND:	*No trouble can be found.
2.	AF-ASV:	*In AF-S and M modes, exposure and AF indicators do not appear. Shutter release operation is impossible. *All are in "A" mode except AF-C and exposure mode "M". AF indicator does not appear. Shutter release operation is possible. *AF filter change over operation is repeated slowly for 16 seconds after auto film loading.
3.	AF-ABLE:	*In AF-M mode and focus aid operations are possible. Shutter can be released. *In AF-S and C modes, lens vibrates slightly and goes in focus. Shutter release operation is possible. *AF filter change over operation is done little by little and stops. *Exposure display is normal.
4.	RLS-ABLE:	*In AF-M mode, focus aid and shutter release operations are possible. *In AF-S mode, Shutter can be released even when subject is not in focus. (Sometimes shutter can not be released.) *AF-C mode is normal.
5.	AF-RESET:	*Exposure display is normal. *All are in "A" mode except exposure mode "M". *Auto film loading is impossible, shutter cannot be released. (Shutter can be released when film is not loaded.) (During shooting, shutter release and film rewind operations become impossible.)
6.	AF-R.SW Sig:	*No trouble can be found.
7.	AF-H.Sig:	*In AF-M mode, focus aid and shutter release operations are possible. *In AF-S mode, no AF indicator appears and shutter release operation is impossible. *In AF-C mode, no AF indicator appears and shutter release operation is possible. (Either one of focus indicators lights up during shutter release operation.)
8.	AF.R.Sig:	*No trouble can be found.
9.	FD-1:	*AF filter change over operation does not work after auto film loading. *Others are in normal.
10.	AF-D.GND:	No trouble can be found.
	L.E.A.:	*All are in "A" mode except exposure mode "M". *AF indicator does not appear. *In AF-M mode, shutter release operation are not possible. *In AF-S, C mode, shutter release operation are possible. *No auto film loading is possible.
12.	FD.O:	*After auto film loading, film rewind motor rotation does not stop.
13.	CTL3:	*AF indicator does not appear. *Lens does not operate. *All are in "A" mode except exposure mode "M". *Auto film loading is impossible. *Shutter cannot be released. (Shutter can be released when film is not loaded.)

14.	FILTER:	*No trouble can be found.
15.	LD:	*No trouble can be found.
16.	AF-D5V:	*No trouble can be found.
17.	DC:	*All are in "A" mode except exposure mode "M". (Others are in normal.)
18.	AF-3V:	*In AF-M mode, focus aid and shutter release operation are possible. *In AF-S, C modes, hunting occurs at in focus position. (Sometimes shutter release operation is possible.) *Volume of scanning is insufficient.
19.	AF-12V:	*AF indicator remains to show "X" and does not change. *In AF-M mode, shutter can be released. *In AF-S mode, shutter cannot be released. *In AF-C mode, there is time lag from shutter release switch is ON until shutter is released. Shutter cannot be released by pressing shutter release button slightly.
20.	AF-CLK:	*AF indicator does not appear. *Lens does not operate. *Shutter can be released. *All are in "A" mode except exposure mode "M". *Film is loaded, auto film loading is impossible. Shutter cannot be released. (During shooting, above phenomenon occurs and film rewind becomes impossible.)
21.	CTL1:	*All are in "A" mode except exposure model "M". *No other trouble can be found.
22.	AF-1/O:	*AF indicator does not appear. *Lens does not operate. Shutter can be released. All are in "A" mode except exposure mode "M". *Film is loaded, auto film loading is impossible. Shutter can be released.
23.	CTL2:	*No trouble can be found.
24.	(NC):	


- * When either one of following pins is disconnected, the trouble can be detected through communication inspection to front body.
Pin 2, 5, 13, 20, or 22
- * In AF connector at AF base plate side in some of the initially produced bodies, double coated adhesive tape has been used as an adhesive agent. In this body, the connector may become disconnected because the tape protrudes out of the connector. Fully clean the connector using alcohol, and insert in the 24-pin connector at main FPC side.
If double coated adhesive tape is found in 24-pin connector at main FPC side, replace the 24-pin connector.



Z-2	List of trouble due to disconnection of cords around film advance base plate.
1.	Charging switch (gray cord) remains ON or short-circuit to body.
Phenomenon	It performs continuous mechanical charging when shutter release button is pressed lightly.
2.	Charging switch is disconnected or not turned ON.
Phenomenon	Camera back opened: It performs continuous mechanical charging when shutter is released. Camera back closed: Mirror does not move smoothly during mirror moving up, and sequence error display appears after mirror moves down.
3.	Film advance completion switch (white cord) remains ON or short-circuit to body.
Phenomenon	External alert LED lights up when shutter release button is pressed lightly.
4.	Film advance completion switch is disconnected or is not turned ON.
Phenomenon	[Film loaded]: Spool motor does not rotate. (Auto film loading is impossible.) In mechanical charging only, blank exposures are repeated.
5.	Mechanical charging switch (gray cord) and P.I cord (pink cord) are short-circuited.
Phenomenon1	[Film not loaded, or camera back opened or closed]: (1) Mechanical charging is performed little by little when shutter is released. (2) Spool motor does not rotate.
Phenomenon2	[Film loaded]: (1) Auto film loading is impossible, spool motor alone rotates and advances film when shutter release button is pressed lightly, alert LED lights up at end of roll and spool motor stops. (2) Auto film rewinding is impossible.
6.	Either one of P.I cords (green, blue, pink) is detached. Either one of P.I cords (green, blue, pink) is short-circuited to each other. Either one of P.I cords (green, blue, pink) is short-circuited to GND.
Phenomenon	Cs mode becomes CH mode. Other operations are normal.

2-3	List of trouble due to poor soldering between main FPC and nine soldered portions of DB/FD/DX FPCs. Conditions: DP-20, SB-24, and AF zoom lens are mounted.
-----	--

List of trouble when each land of nine soldered bridges is disconnected (open).				
Inspection items	Body side	Viewfinder side	Flash side	Other
	LCD/LED display Display illuminator Shutter release AF operation Shutter speed	LCD display Display illuminator	Communication (zoom, aperture, film speed) Firing Light output measurement	
Check the cause of trouble carefully before starting repair procedures because the cause of trouble may be found in body, viewfinder, or flash. *List of trouble was made after having made inspection of each item of above items. *No description was made for the items in which no trouble was found. (Blank) ("No trouble can be found" does not mean that operation is normal.) For example, no communication is made between body and flash in the list of trouble, you can confirm it by checking that LCD panel of flash (SB-24) does not change when operating film speed dial in body, zooming lens, or controlling aperture.				



Land name	Phenomenon at body side	Phenomenon at viewfinder side	Phenomenon at flash side
SB READY2	Flash ready-light does not light up. Does not change over to sync shutter speed		No communication between flash and body.
SB STOP2			No communication between flash and body. Flash fires fully in TTL mode.
SB TTL			No communication between flash and body. TTL-BL is impossible.
FD 5V	Flash ready-light does not light up. Does not change over to sync shutter speed.	No display appears.	No communication between flash and body. Flash fires fully in TTL mode.
FD GND		No display appears.	
FD 3V	Shutter cannot be released. No LCD display appears. Illuminator does not light up. AF indicators and operation are normal.	No display appears. Illuminator does not light up.	No communication between flash and body.
FD CLK	LCD display is stable. FD detection indicators appear alternately.	No display appears. Illuminator does not light up.	
FD I/O		Metering mode does not change over.	
FC I/O		No display appears. Illuminator does not light up.	

ASS13MBLING & ADJUSTMENT

Contents

Assembling, back body]

Camera back parts	A1
Bottom cover and tripod parts	A2
Film advance side cover, Film rewind side top cover	A3
Back body parts	A4
Sync contact, film detection switch	A7
FD, DBor DXFPC unit	A8
Shutter unit	A9
Film rewind motor	A9
Film rewind unit	A11
Upper film advance parts	A12
Film advance baseplate	A13
Film advance base plate unit, disassembly, assembling	A14
Mounting film advance baseplate unit	A22
Shutter release fig, Lever under shutter release through shaft	A25
DC-DC converter base plate	A26
Power TrFPC unit	A26
Shutter speed dial base plate	A27
Mounting Main FPC	A28
Checking camera'back	A28

[Assembling, front body]


Front body parts	A29
AF baseplate unit, fo baseplate unit	A32
Mirror box unit parts	A33
Mirror box unit	A34
Mounting mirror unit, I baseplate, L baseplate	A36
Mounting mirror box, front body	A36
Filter driving base plate, filter unit, TTLSPD unit	A37
Seesaw lever	A37
AF rnodeselect.or lever unit	A37
Lens release button switch	A37
Mirror operation base plate unit	A38
f-fo base plate, f-fo pulley	A38
Lock encoder FPC unit	A41
Cable arrangement on the lower part of the L baseplate	A41

AF base plate unit	----- .----- ----- -----	A41
Positioning adjustment of fmm switch	----- --	A42
Height adjustment of aperture lever	----- -	A43
Height adjustment of AF coupling ring shaft	----- .----- .-----	A43
Angle adjustment (45°) of main mirror (G1) sub-mirror (G2)	-----	A44


[Mounting of front body and back body]

Mounting of front body and back body	----- .----- .-----	A45
Adjustment of film sprocket cogwheel positioning	----- .----- .-----	A48
Adjustment of body back	----- .----- .-----	A49
Adjustment of infinity	----- .-----	A49
AE, AF Accuracy, inspection, and adjustment	-----	A49


Camera back parts



Bottom cover and tripod parts





Film advance side top cover
Film rewind side top cover




Back body parts

- Spread G103 on the body and paste,









Sync contact, film detection switch

- Sync contact




- Film detection switch

Film detection switch



- junction cable



Check the ON-OFF position of the film detection switch based on the external film guide rail:
Height (or play); $a = 1.13 \pm 0.15$
ON-OFF switching position; $b = 1.00$ or more
Total stroke; More than 0.1 deeper from the external film guide rail.

FD, DB, or DX FPC unit

Thyristor trigger base plate

FD contact FPC

Blue
Yellow
Orange

DB contact FPC

DX contacts

X (green) : from sync contact

X (green) : from FD contact

GND (black): from sync contact

GND (black) : from FD contact

Mount FD, DB, and DX FPCS

Left side of FD contacts mold

Spread a small of adhesive on contact mold

5 minute epoxy

#1022 x 2

#1040 x 2

679 X 2

Place the DB contact FPC through the hole of the body

#1040 x 2

#1022 x 2

#678 X 2

DB contact cover
#1127x2

Light leakage protective
MIRROR on the DB

Attach light leakage protective plastic sheet on the DB

DB contact cover

Solder cables

Arrange cables

Cable arrangement

Tape for arranging cables

#1127 x2

#869


#864

R2 lever


Check the latching condition of the R2 lever

The latching amount of the #864 and #869 when the R2 lever is in locked state;
 $A \div B$ (approx. 0.7)

Adjust by bending part C indicated by the arrow in the figure at left.




Shutter unit




Shutter unit
#66
#68
#1135

Film rewind motor unit




Mount a film rewind
coupling shaft in the
film rewind motor unit.



Mount a film rewind
motor unit
#39
#40
#1019 x 2


&
Lock tight Ⓢ #1019 x 2
(Purple)



Check the position of
the filter selection
lever

The tip of the filter
selection lever (as
shown in the figure)
should be located
within the range of
approx. 0.4 from the
lower end of the
shutter.

Adjust by bending the
part B as shown in the
figure .



Arrange film rewind
motor cables.
#964 x 3

Film rewind unit

Film rewind mold
base plate

Camera back
switch

R, SW

#1113 x 3%

Film rewind
base plate

G7100

Fork gear

G7100

Check following items:


1. Gaps (up and down) of the film rewind shaft;
0.1 - 0.3
2. ON-OFF operation of the camera back switch.
3. ON-OFF operation of the R2 SW.


Camera back
switch pin

Film rewind shaft






Insert the film rewind
shaft from the other end.

4. Lock the R2 lever (move the lever up) . Check to see if there is irregular rotation and strange sound when rotating the film rewind shaft.






Film advance base plate



Film advance base plate unit,
disassembling, assembling

== Disassembling ==



1) Upper film advance unit
(frame counter unit)

Pulse PI #1107

Pulse blade


E clip #1087

(Do not remove pulse
driving gear)

Multiple exposure relay
lever shaft



Multiple exposure relay
lever

Multiple exposure relay
lever wire




#1106x3


2) Film take-up spool motor
(FM) #1019x2 #476




3) Inside film advance unit



Inside film advance unit





4) Shutter charge motor (MM) #1019x2

Assembling

(See page A12 for applying oil and attaching)

1) Shutter charge motor (MM)


#1019x2

Mount the motor by moving aside in the direction indicated by arrow.

Check the condition of the Film Sprocket shaft Film advance completion.


Fig. below:
Film sprocket advance completion state.

Set the Film Sprocket shaft to the film advance completion state




(1) Portions b and c (as shown in the figure) of the film advance stopper will be disengaged from the film advance stopper latch lever when the shutter charge cam is rotated in the direction indicated by arrow a.

(2) Portions b and c will be engaged when the film advance stopper click moves toward the portion e by rotating the Film Sprocket shaft in the direction indicated by arrow d (as shown in the figure). Check to see if the overcharged amount of the film advance stopper latch lever and the stopper is more than 0.2 by rotating the film sprocket shaft in the direction indicated by arrow d. (See left figure)




2) Inside film advance unit



Mount this by rotating the inside film advance unit in the direction indicated by arrow b while pulling the spring (#539) in the direction indicated by arrow a.


Note : Care should be taken not to pinch the spring (#539) between the lower film advance unit and the inside film advance unit.




#1106 x 3

#1106 x 3
Screw lock (#350)

3) Film take-up spool motor (FM)
#476
#1019x2



4) Mounting gears



Gear S10

Gear S9

Film take-up spool
clutch lever #1087

Film take-up spool
clutch spring

Gear C11 #1102


Gear C9

Gear S2

Gear S7


Apply oil (G92KA)
to each gear.
Dip the gear S2
in oil barrier

Film take-up
spool clutch spring




Check the film take-up
spool clutch lever
latching amount

Film take-up spool
clutch lever



Length b should be more
than half of length a.

View A



5) Upper film advance unit


Frame counter reset spring

Frame counter gear
Fix with a stopper after rotation the gear two turns in the direction indicated by arrow a (clockwise)

#583

Frame counter scale
Use G103 to stick the projected portion of the frame counter gear and the caved portion of the frame counter scale.

Frame counter scale plate mask #1010



Cut-out #576

Cut-out of #576 should be faced with #577.

Adhere each screw with screw lock (#350) .
Apply oil (G92KA' on each gear and lever.

Inspection (ON-OFF)

" Shutter charge completion switch

• Film advance completion switch


• Frame counter switch

Frame counter scale goes off between frame counter 0 and 1 when the frame counter gear is rotated clockwise.

• Check the location of the frame counter scale mask

Frame counter scale is within the range of more than 2/3 of the width of the counter index (counter scale plate mask) . See the figure at left.

Adjustment : Adjust by moving the frame counter scale plate mask after unfastening #1010.



6)-Mounting upper film advance unit




*Small parts (see page A14)

Lower film advance unit assembly

Upper film advance unit


Screw lock
(#350)

#1106x3



Film advance
completion sw

Film rewind coupling
slide lever




Lower film advance unit assembly

Set the film sprocket shaft and the shutter charge cam to the film advance completion state.

Upper film advance unit

Set the cut-out of #576 to the proper place as shown in the figure at left.




Mount the unit so that the contacts of the film advance completion switch comes to the location indicated by a in the lower film advance unit assembly, and the film rewind coupling slide lever comes to the location indicated by b in the lower film advance unit assembly. (See above figure)




#1106x3

On-off inspection of film advance completion switch


Film sprocket shaft is in the film advance completion state.



(2) The gap between the lower part of the thermal contraction tube (#564) and the upper side of #B531 and #B533 is more than 0.2 when rotating the film sprocket shaft while depressing #B519 in the direction indicated by arrow a.




(3) Depress #519 in the direction indicated by arrow a while film sprocket shaft is in film advance completion state. (Set to the film advance stopper release state.) Make sure that film advance completion switch goes on by #B531 and the gap between the thermal contraction tube (#564) and #602 is more than 0.2.



(4) Rotate the film sprocket shaft in the above state. Make sure that the film advance completion switch goes on by B533 instead of #531. And the gap between the thermal contraction tube (#564) and #602 is more than 0.2.



Mounting film advance base plate unit

Figure below: Film advance completion state



1) Mounting film take-up spool

Install a film take-up spool after mounting a film take-up spool spring as shown in the figure.




Film advance base plate positioning pin

G7100

Camera back opening/
closing coupling pin


Shutter
T lever

Z) Latched portion
of film advance base
plate and shutter.
•: Indicating
latched portion



Shutter charge lever

Shutter Mg set lever
(in reset state)



Shutter
release
lever

Resetting method
Reset the shutter Mg
set lever by
depressing the lever
on the shutter
release through
shaft (see page A22)
while setting it to
the film advance
completion state by
rotating the shutter
charge cam
counterclockwise .

3) How to install film
advance base plate unit.

(1) Reset the shutter Mg set
lever by depressing the
lever on the shutter
release through shaft
after setting to the film
advance completion state
by rotating the shutter
charge cam
counterclockwise .

(2) Set to the film sprocket
shaft advance completion
state by rotating the
film sprocket shaft
counterclockwise .


(3) Mount the film advance
base Plate by pulling the
EL roller forward.

Note:

- Film advance base plate should be surely fixed in the film advance base plate positioning pin.
- Film advance base plate and shutter are surely latched.
- Film take-up spool motor (FM) cables should not be pinched.

#1049x2

#774



Left side
offilm sprocket
screw (#1074)

Pull the EL roller forward and
mount a film take-up spool
on the film advance base plate unit.

- (4) (See page A21)
Mount film advance base plate mounting screws (#1049x2, #774) after resetting the film advance stopper by depressing B519 in the direction indicated by arrow a.

Temporarily fasten the film sprocket screw (#1074x1) (the left side sprocket screw)


Inspection

- a. Shutter charge
Rotate the shutter charge cam counterclockwise.
- b. Shutter release
Depress the lever on the shutter release through shaft


It turns to T (time)

Reset the T by moving the T lever in film rewind direction.

- (5) Cable arrangement
(□: Junction cables)



Shutter release Mg,
Lever under shutter release through shaft




#G2KA

ever under
shutter release
through shaft
and its bearing
(release Mg)

Shutter
release Mg
(red)

(black) Adhesive tape
for arranging cables


Spring latching



Inspection


- Thrust play of shutter release through shaft:
0.1 -- 0.3
- charge amount of the lever under the shutter release through shaft:
More than 0.2
Check the charge amount by rotating the shutter charge cam counterclockwise.

DC-DC converter base plate




*Be sure not to pinch cables.

Power Tr FPC unit




Soldering of cables




Shutter speed dial base plate

- 1) T (time) lever
RI set lever
Latched position



- T (time) lever

See the portion indicated by a in the figure.



- RI set lever

See the portion indicated by b in the figure.

RI set lever on the film advance base plate (upper film advance unit-) and RI sw lever on the shutter speed dial base plate should be latched.

- 2) Mounting shutter speed dial base plate


#1050
#1054
#1106

Solder

- 3) Soldering cables

Adhesive tape
for arranging cables

(frame counter switch)



Pulse PI (green)

'se'PI (blue)

b


Shutter charge
completion switch (grey)

Pulse PI (pink)


<Film advance
completion switch (white)

Mounting Main FPC

Refer to pages D10 to D11 when mounting main FPC .



- a. Insulating tape
- b. Adhesive tape for arranging cables. Adhere cables on the rear side of the main FPC.

Checking camera back

(Refer to above figures)

- 1) Set the SC base plate as shown in the above figure.
- 2) Press contact the film advance side press contact.
- 3) Supply 5.5V power to the power supply base plate.
- 4) Mount a shutter release tool (self-made tool)

Note : Set the shutter speed dial to 1/4000 sec. or slower until AE adjustment is completed.


A. Check the back body (as shown on page A28) .


- Set the exposure selector mode to M
- Turn off the camera back switch (push the camera back switch pin)
 - (1) Shutter release
 - (2) Shutter speed
 - (3) Mechanical shutter charge sequence
 - (4) S-C mode (L, S, C_H, C_L, C_S, Self-timer)


B. Personal computer and back body inspection
(Hook up personal computer and communication tool [J15279])

- (1) Inspection of operation
 - Film take-up spool motor
 - Film rewind motor
 - Shutter release
 - Mechanical shutter charge sequence
- (2) Inspection of switches
- (3) Inspection of dials
- (4) Inspection of LCD display


Front body parts









- 1) Checking double lock switch
The switch turns on when the double lock knob is set to the double lock side.



- 2) Checking EE recognition switch
The switch turns off at the height of 0.3 to 0.85mm from the bayonet ring surface.



AF base plate unit, fo base plate unit



Mount the fo lever on the AF base plate unit,

Mount the AF base plate unit on the front body by adjusting levers and pin indicated by arrows in the figures:


a - a': fo lever
b - b': AF coupling lever
c - c': AF base plate positioning pin

#1048x2

Hook the AF lever spring (#410) on the hook.

Checking fo base plate brush positioning



Adjustment of brush position on fo base plate



There should be a space between brush contact portion and end of fo pattern when lens is not attached.




Mirror box unit



— Aperture Mg (See page D23)

Aperture Mg click — Adjust the gap between the click and the ratchet gear.



Mounting mirror unit, I base plate, L base plate

See page D23


Mounting mirror box, front body

See page D22

Adjust thrust play of mirror unit
Rated value: 0.1 to 0.3
Adjustment washer

1K050-334	0.1
1K050-335	0.05
1K050-336	0.15
1K050-337	0.2
1K050-338	0.3

Cable arrangement



Filter driving base plate, filter unit, TTL SPD unit

See pages D20 to D21

– Filter unit

Check: Filter mirror holder moves by its own weight when the front body is declined after assembly.

– Filter driving base plate unit

Check: Check to see if the filters are switchable after assembly.

Seesaw lever

See page D19.

AF mode selector lever unit

See page D19.

Lens release button switch


See page D18.

Check AF switch 1, AF switch 2, lens release button switch


Check continuity of each switch by "connecting GND (body) and AF switch 1 (blue), and GND and AF switch 2 (white) using a tester.

(1) AF switch inspection

	AF switch 1 (blue)	AF switch (white)
∞ mode	off	on
3 mode	on	off
1 mode I	off	off



- (2) Lens release button switch inspection
AF switch 1 and AF switch 2 turn off when the lens release pin is within the range of 0.45 to 0.85 from the bayonet ring.



Mirror operation base plate unit

See page D17.

Check preview bottom and mirror up operations


f-fo base plate, f-fo pulley

– f-fo base plate

See page D18.

– f-fo pulley

Mount by rotating the pulley once clockwise while aligning the f-fo pulley spring (#402) with the f-fo pulley shaft groove.



Note : Do not damage the plastic mold shaft of the f-fo pulley.

Reel aperture coupling ring thread in the #403 groove. (See figure a)


Note :
(1) Thread knot should not be pushed out from the surface of the f-fo base plate.

(2) Aperture coupling ring thread should be hooked in the roller on the AF mode selector base plate.

(3) Aperture coupling ring thread should not be bent.


1) Adjustment of f-fo pulley stop position

Aperture coupling ring is attached to the stopper.




The f-fo pulley is being attached to the stopper.

Use adhesive (Alon Alfa) to attach.



Adjust by rotating #403 so that the aperture coupling ring and the f-fo pulley come into contact with the stopper simultaneously.

2) Adjustment of the f-fo base plate position.



- (1) Mount the f-fo tool lens (J18202) on the body.
- (2) Set the digital voltmeter (at the resistance measuring range) as shown in Fig. a.
- (3) Adjust by rotating the f-fo base plate so that each resistance value can be measured when the f-fo tool lens (J18202) is moved aside as shown in Fig. b.

Resistance value is 624 to 936 Ω when the tool lens is moved in the direction indicated by arrow c. Resistance value is 0 Ω when moved in the direction indicated by arrow d.

- (4) Fasten screws (#1010x2) and spread screw lock (#350) on them.





Fig. b

– Soldering cables

Solder AGND (blue) and Vref (purple) on the f-fo base plate.



– When f-fo pulley shaft is damaged.

- (1) Remove the f-fo pulley and the f-fo base plate.
- (2) Remove the damaged f-fo pulley shaft.
 Note: Check to see if there are any broken pieces left in the L base plate.
- (3) Mount the f-fo pulley shaft (1K371-359) .
- (4) Spread adhesive (Alon Alfa) at the portion where the f-fo pulley shaft is mounted.


Lock encoder FPC unit

See page D17.

Cable arrangement on the lower part of the L base plate

Hook AF motor cables on the holder.

Use adhesive (3103) to attach Vref (purple), -fo (yellow) and GND (blue).



Vref (purple)
AGND (blue)


AF switch 1 (blue)
AF switch 2 (white)

AF motor (red), (black)

AF base plate unit

See pages D15 to D16.

Positioning adjustment of fmm switch



(1) Connect a tester between the TC switch (white) and the body (GND) .

(2) Mount the 50mm (f/1.4) AI lens on the body. Do not move any further once the protection ring of the 50mm f/1.4 AI lens (indicated by arrow a) pushes the fmm signal lever.


(3) Fasten the fmm base plate at the point when the TC switch is changed from ON to OFF by moving the fmm base plate. Then the fmm signal lever brush should be positioned at the center of the TC switch and the fmm switch patterns.

(4) The fmm switch should be off when the 50mm f/1.4 AI lens is removed.

Noi_e : Correct lens:


50mm f/1.4 AI

(Do not use 50mm f/1.4 AI-S and AF 50mm f/1.4.)




Height adjustment of aperture lever

Rated value : $3.4 \begin{smallmatrix} +0.1 \\ -0.05 \end{smallmatrix}$




Height adjustment of AF coupling ring shaft

Adjust the height by turning the screw (#1078) so that the AF coupling shaft is higher by 1.6 ± 0.1 than the bayonet surface when the lens release button is free in AF-C or AF-S mode .



Angle adjustment (45°) of main mirror (G1), sub-mirror (G2)

- Angle adjustment (45°) of main mirror (G1)



Tool: . J18037 (Optical flat)


- J18038
- Vertical collimator
- Hex key

Rated value:

Horizontal discrepancy;
 $0 \pm 18'$

Vertical discrepancy;
 $0 +0'$
 $-10'$

Adjust by moving
B204 vertically.



Adjustment of vertical discrepancy

Adjust by rotating #239.


- Angle adjustment (45°) of sub-mirror (G2)

Tool: • J18196 (determines the
angle (45°) of the sub-
mirror)

- Vertical collimator

Rated value:

Vertical discrepancy;
 $5 \times 5'$




Adjustment of vertical discrepancy

Adjust by rotating #253.

Mounting on front body and back body

– Preparation for mounting on front body side




- 1) Move the mirror down
 - Move the mirror down by pressing the shutter charge lever to the bayonet ring.
 - Spread G7100 on the tip of the shutter charge lever, and start lever.
- 2) Move aside the filter driving coupling lever to film rewind side or in the direction indicated by arrow a.

Note : Eliminate foreign matter in the filter and AF sensor units by using a blower.

– Preparation for mounting on back of body

- 1) The body should be set in the film advance completion state.



Shutter charge lever


Shutter release lever

Shutter release lever
should be set to the far
back position.

Mirror down lever


Note: Check that the T (time) lever is correctly
latched. (See page A27)

- 2) Set the shutter speed dial to the T (time) position,
- 3) Move the filter driving coupling lever to the film
rewind side.



* Set the clutch pin at this position and fix the
filter driving coupling lever.



- Mounting



Assembling: See pages D3 to D5.

Adjustment of film sprocket cogwheel positioning

- 1) Set the body to the film advance completion state.
- 2) Unfasten the film sprocket screw (#1074x1) .
- 3) Set the film sprocket cogwheel positioning tool (J18064-1) on the aperture surface.
- 4) Fasten the film sprocket screw (#1074) temporarily after aligning the right end of the film sprocket cogwheel to the position 31.8. Adjust it further so that the right end of the film sprocket cogwheel will be within the range of 31.8 ± 0.2 when moving the film sprocket in the direction indicated by arrow a.



- 5) Mount the film sprocket screw (#1074) with lock tight (purple) in the left film sprocket screw hole (indicated by arrow b).
- 6) Check to see the film sprocket cogwheel position by repeating film advance operation several times.

Adjustment of body back

Same as for F3 and other models.

Adjustment of infinity

Same as for F3 and other models.

AE, AF Accuracy, inspection, and adjustment

AE accuracy inspection and adjustment items (following instructions by personal computer)

1. AE accuracy inspection, adjustment

Sub-menu	Inspection, adjustment items
1. F4 + AMP.FD	Spot exposure metering ad-justment-> AMP exposure metering —————>(1)
2. F4	Spot exposure metering adjustment->(1)
3. AMP.FD	AMP exposure metering adjustment (adjust by mounting on the tool body)
4. F4 + Action FD	Spot exposure metering -> Center-weighted exposure metering->(1)
5. Action FD	:Center-weighted exposure metering (adjust by mounting on the tool body)
(1) -> Adjust M 1/8000 (M 1/4000) -> TTL adjustment (Adjust by mounting AMP.FD or Action FD)	

2) When main FPC on the F4 body or EEPROM is replaced:

1) Make following adjustment (write AF compensation value into EEPROM) after the inspection of item 1.
-> X BER P adjustment -> AZ adjustment -> Hard AGC adjustment

- AF accuracy inspection, adjustment items (following instructions by personal computer)

Note :

- 1) When making adjustment of AF accuracy, remove bottom cover, tripod socket (see page D2), bottom FPC screw (#685, #1026, #1038) (see page D6), and set up the bottom FPC unit.
- 2) When making adjustment, close the viewfinder eyepiece shutter or cover the body with black cloth.
- 3) When viewfinder is not attached, adjust the Az by aligning the AF inspection chart and target zone on the focusing screen.
- 4) It is not required to attach AF sensor adjustment screws (x 3) with screw lock.

1) AF accuracy inspection (adjustment when disassembling AF sensor unit)	2) AF Sensor (when displacing)	3) Main FPC of F'4 body (when displacing main FPC or EEPROM)
X BER P inspection and adjustment YAW inspection and adjustment PITCH inspection and adjustment Az inspection and adjustment	X BER P adjustment YAW adjustment PITCH adjustment AZ adjustment Hard AGC adjustment	After AE adjustment, write following compensation value into EEPROM X BER P adjustment AZ adjustment Hard AGC adjustment